Original	Replacement	Original	Replacement
Power	Power	Mute	Mute
Red/Disc	Red	Stop/Eject	Stop
Green/Dock for	Green	Play	Play
Yellow/Help	Yellow	Pause	Pause
Blue/♪ Source	Blue	I<	I<<
Pop-Up Menu/Disc Menu	Menu	<<	<<
Home	Smart	>>	>>
III/Sound Settin	Dual	>I	>>I
Back	Back	1	1
Options	Options	2	2
Up	Up	3	3
Down	Down	4	4
Right	Right	5	5
Left	Left	6	6
OK	Ok	7	7
Vol +	Vol +	8	8
Vol -	Vol -	9	9

Original	Replacement	Original	Replacement
0	0		
Top Menu	SHIFT + TOP MENU MENU Shift + Menu		
Subtitle	AD SUBT Subt		