Mandis shop

Philips 996510066677

Original		Replacement	
	Power		Power
CD	CD	1	1
USB A	USB A	2	2
+ VOL	Vol+	+ VOL	Vol +
VOL −	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
DBB	DBB	PICTURE FORMAT	Format
DSC	DSC	ECO 3D	3D
TUNER	Tuner	3	3
Bluetooth	Bluetooth	4	4
AUX	AUX	5	5
AUDIO A	Audio A	6	6
▶II	Play/Pause CD / Tuner / Audio A	OK	Ok
■	Stop CD / Tuner / AUX / Audio A	■	Stop
USB RECORD	USB Record CD / AUX / Audio A	REC MODE	Rec
USB DELETE	USB Delete CD / AUX / Audio A	CLEAR EXIT	Exit
MODE	Mode CD / AUX / Audio A	TOP MENU MENU	Menu

Original		Replacement	
■	Stop USB B CD / Tuner / AUX /	APP MEDIA	Media
▶II	Play/Pause USB B CD / Tuner / AUX /	PLAY MODE ▶	Play
AUTO DJ	Auto DJ CD / AUX / Audio A	RETURN BACK	Back
LIGHT	Light CD / AUX / Audio A	DISPLAY INFO	Info
+ ALB/ PRESET	Alb/Preset+ CD / Tuner / AUX /	+ CH	Ch +
ALB/ PRESET −	Alb/Preset- CD / Tuner / AUX /	CH −	Ch -
PROG	Prog CD / AUX / Audio A	SETTINGS OPT	Options
	Power USB A / Bluetooth	SHIFT +	Shift + Power
▶▶	>> CD / AUX / Audio A	▲	Up
◀◀	<< CD / AUX / Audio A	▼	Down
▶I	>I CD / Tuner / AUX / Audio A	▶	Right
I◀	I< CD / Tuner /AUX / Audio A	◀	Left
PROG	Prog USB A / Bluetooth	SHIFT + SETTINGS OPT	Shift + Options
+ ALB/ PRESET	Alb/Preset+ USB A / Bluetooth	SHIFT + + CH	Shift + Ch +
ALB/ PRESET −	Alb/Preset- USB A / Bluetooth	SHIFT + CH −	Shift + Ch -
■	Stop USB A	SHIFT + ■	Shift + Stop
▶II	Play/Pause USB B USB A / Bluetooth	SHIFT + PLAY MODE ▶	Shift + Play

Original	Replacement	Original	Replacement
Stop USB B USB A / Bluetooth	SHIFT + MEDIA — Shift + Media		
Light USB A / Bluetooth	SHIFT + INFO — Shift + Info		
Auto DJ USB A / Bluetooth	SHIFT + BACK — Shift + Back		
Play USB A / Bluetooth	SHIFT + OK — Shift + Ok		
<< USB A / Bluetooth	SHIFT + ▼ — Shift + Down		
>> USB A / Bluetooth	SHIFT + ▲ — Shift + Up		
>I USB A / Bluetooth	SHIFT + ▶ — Shift + Right		
I< USB A / Bluetooth	SHIFT + ◀ — Shift + Left		
Power Tuner	0 — 0		
>> Tuner	>> — >>		
<< Tuner	<< — <<		
Light Tuner	TV/R — TV/R		
Mode USB A	SHIFT + MENU — Shift + Menu		
Power AUX /	SHIFT + 0 — Shift + 0		