Original		Replacement	
	Power		Power
MODE	Mode	FORMAT PICTURE	Picture / Format
SCAN	Scan	LIST SMART	Smart / List
DIM	DIM	TOP MENU D.MENU	D. Menu / Top
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
	Eject	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
INFO RDS	RDS/Info	ANGLE INFO	Info / Angle
ALBUM	Album Up		Up
	Album Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
	I<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement	
	Stop	HOLD	Stop / Hold
	>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
LOUDNESS	Loudness	EQ SUBTITLE	Subtitle / EQ
CLOCK	Clock	MEDIA DISPLAY	Display / Media
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
TREBLE	Treble	+ CH PAGE	CH+ / Page+
BASS	Bass	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Replacement		Original	Replacement
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /		
SHIFT	Shift	RDS AV INPUT	AV / Input / RDS		

Original		Replacement	
	Power		Power
MODE	Mode	FORMAT PICTURE	Picture / Format
SCAN	Scan	LIST SMART	Smart / List
DIM	DIM	TOP MENU D.MENU	D. Menu / Top
TIMER	Timer	SHIFT +	TIMER SLEEP Shift + Sleep / Timer
	Eject	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
INFO RDS	RDS/Info	ANGLE INFO	Info / Angle
ALBUM	Album Up		Up
	Album Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
	I<	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow

Original		Replacement	
	Stop	HOLD	Stop / Hold
	>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
LOUDNESS	Loudness	EQ SUBTITLE	Subtitle / EQ
CLOCK	Clock	MEDIA DISPLAY	Display / Media
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
TREBLE	Treble	+ CH PAGE	CH+ / Page+
BASS	Bass	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Replacement		Original	Replacement
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /		
SHIFT	Shift	RDS AV INPUT	AV / Input / RDS		

Original		Replacement	
	Power		Power
MODE	Mode	FORMAT PICTURE	Picture / Format
SCAN	Scan	LIST SMART	Smart / List
DIM	DIM	TOP MENU D.MENU	D. Menu / Top
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
	Eject	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
INFO RDS	RDS/Info	ANGLE INFO	Info / Angle
ALBUM	Album Up		Up
	Album Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
	I<	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow

Original		Replacement	
	Stop	HOLD	Stop / Hold
	>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
LOUDNESS	Loudness	EQ SUBTITLE	Subtitle / EQ
CLOCK	Clock	MEDIA DISPLAY	Display / Media
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
TREBLE	Treble	+ CH PAGE	CH+ / Page+
BASS	Bass	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Replacement		Original	Replacement
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /		
SHIFT	Shift	RDS AV INPUT	AV / Input / RDS		

Original		Replacement	
	Power		Power
MODE	Mode	FORMAT PICTURE	Picture / Format
DIM	DIM	TOP MENU D.MENU	D. Menu / Top
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SCAN	Scan	LIST SMART	Smart / List
TIMER	Timer	SHIFT +	TIMER SLEEP Shift + Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
INFO RDS	RDS/Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
LOUDNESS	Loudness	EQ SUBTITLE	Subtitle / EQ
CLOCK	Clock	MEDIA DISPLAY	Display / Media
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
TREBLE	Treble	+ CH PAGE	CH+ / Page+
BASS	Bass	CH PAGE –	CH- / Page-
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow

Original		Replacement	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	I <	PRESET-	I << / Preset-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	>I	PRESET+	>>I / Preset+
OK	OK	OK	OK
ALBUM	Album Up		Up
	Album Down		Down
	Right		Right
	Left		Left
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
	Eject	SURROUND	Eject / Surround
SHIFT	Shift	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Replacement	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
Power	DAB/ FM	SHIFT + Power	Shift + Power
SCAN	Scan DAB/ FM	SHIFT + LIST SMART	Shift + Smart / List
OK	OK DAB/ FM	SHIFT + OK	Shift + OK
ALBUM ▲	Album Up	SHIFT + ▲	Shift + Up
▼	Album Down	SHIFT + ▼	Shift + Down
▶	Right DAB/ FM	SHIFT + ▶	Shift + Right
MODE	Mode DAB/ FM	SHIFT + FORMAT PICTURE	Shift + Picture / Format
◀	Left DAB/ FM	SHIFT + ◀	Shift + Left
MENU	Menu DAB/ FM	SHIFT + HOME MENU	Shift + Menu /
INFO RDS	RDS/ Info	SHIFT + ANGLE INFO	Shift + Info / Angle
1	1 DAB/ FM	SHIFT + TV 1	Shift + 1

Original		Replacement	
2	2 DAB/ FM	SHIFT + DVD 2	Shift + 2
3	3 DAB/ FM	SHIFT + CD - STB 3	Shift + 3
4	4 DAB/ FM	SHIFT + VIDEO 4	Shift + 4
5	5 DAB/ FM	SHIFT + TAPE 5	Shift + 5
6	6 DAB/ FM	SHIFT + TUNER 6	Shift + 6
7	7 DAB/ FM	SHIFT + AUX - HDD 7	Shift + 7
8	8 DAB/ FM	SHIFT + USB 8	Shift + 8
9	9 DAB/ FM	SHIFT + BLUETOOTH 9	Shift + 9
0	0 DAB/ FM	SHIFT + HDMI - SAT 0	Shift + 0
⏮	I < DAB/ FM	SHIFT + PRESET- ⏮	Shift + I << / Preset -
⏭	>I DAB/ FM	SHIFT + PRESET+ ⏭	Shift + >>I / Preset +
◀◀	<< DAB/ FM	SHIFT + TUNE- ◀◀	Shift + << /
▶▶	>> DAB/ FM	SHIFT + TUNE+ ▶▶	Shift + >> /
PROGRAM	Program	SHIFT + PROGRAM TV/ RADIO	Shift + TV/ Radio / Program
SHIFT	Shift DAB/ FM	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS