Mandis shop

Pi oneer AXD7472

Original		Replacement		Original	Replacement
Power	Power		Power		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
CD	CD	CD - STB 3	3		
PHONO	Phono	VIDEO 4	4		
TAPE	Tape	TAPE 5	5		
TUNER	Tuner	TUNER 6	6		
AUX	AUX	AUX - HDD 7	7		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
+ VOL	Vol +	+ VOL	Vol +		
VOL –	Vol -	VOL –	Vol -		
TONE/BAL	Tone/ BAL	OK	OK		
L/–	L/-		Left		
R/+	R/+		Right		
DIRECT	Direct	LIST SMART	Smart / List		

https://mandis.es/en/Pioneer/16599234-replacement-remote-control-for-Pioneer-AXD7472-AXD7472.htm