Mandis shop

CU- XR032

Original	Replacement	Original	Replacement
Vol -	Vol -	>>I CD	>>I / Preset+
Vol +	Vol +	Stop CD	Stop / Hold
Sleep	Sleep / Timer	Play CD	Play / Slow
Power	Power	Pause CD	Pause / Step / Freeze
Karaoke	Smart / List	<< Tape I	<< / Tune-
SFC	Picture / Format	>> Tape I	>> / Tune+
P.Bass	Sound / Title	Stop Tape I	Shift + Stop /
Display	Display / Media	<> Tape I	Shift + Play /
AUX	7	<< Tape II	Left
Disc 1	1	>> Tape II	Right
Disc 2	2	Stop Tape I	Down
Disc 3	3	<> Tape II	Up
Clear	Exit / Cancel / Clear	Station Down	CH- / Page-
PGM	Setup / OPT /	Station Up	CH+ / Page+
Repeat	Green / APP / Repeat	Mono	Audio / Lang I/II
Random	Blue / Prime Video / Random	Band	TV/Radio /
I << CD	I << / Preset-		

https://mandisdistance.com/Pioneer/1062-270-replacement-remote-control-for-Pioneer-AC10-CU-XR032.html