Original	Replacement
Eject	Eject / Surround
Standby/On	Power
Menu	Menu / Home
Status/Exit	Exit / Cancel / Clear
Clear	Shift + Exit / Cancel / Clear
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Sleep	Sleep / Timer
0	0
System	Smart / List

Original	Replacement
Record/OTR	Rec / Rec Mode
Up	Up
Play	Play / Slow
>I <I/ Still	Pause / Step / Freeze
<<	<< / Tune-
Left	Left
Right	Right
>>	>> / Tune+
P+	CH+ / Page+
Stop	Stop / Hold
Down	Down
Vol +	Vol +
P-	CH- / Page-
Mute	Mute / Dimmer
Vol -	Vol -
Red/SV/V+	Red / Netflix / Search
Green/Smart Picture	Green / APP / Repeat

Original	Replacement	Original	Replacement
SMART PICTURE Green/Smart	FORMAT PICTURE Picture / Format		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
INDEX Blue/Index	Prime Video RANDOM Blue / Prime Video / Random		
[=i]	ANGLE INFO Info / Angle		
TEXT Text	GOTO TEXT Text / Goto		
[=?]	TOP MENU D.MENU D.Menu / Top		
[=♦]	SIZE ZOOM Zoom / Size		
[=x]	PROGRAM TV/RADIO TV/Radio /		
[=o]	OPT-TOOLS SETUP Setup / OPT /		
[=+]	RDS AV INPUT AV / Input / RDS		