Original		Replacement	
POWER	Power		Power
DSP/EQ	DSP / EQ	APP MEDIA	Media
PL II	Dolby PL II Effe	D	Blue
PL II MODE	Dolby PL II Mode	C	Yellow
	Eject	ZOOM	Eject
DVD	DVD	SHIFT + 1	Shift + 1
TUNER	TUNER	SHIFT + 2	Shift + 2
PORT	PORT	SHIFT + 3	Shift + 3
AUX	AUX	SHIFT + 4	Shift + 4
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
0	0	0	0
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
	I<<		I<<
	>>I		>>I
STEP	Step	SHIFT + II	Shift + Pause
PAUSE	Pause	II	Pause
	<<		<<
	>>		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
VOL +	Vol +	VOL +	Vol +
VOL —	Vol -	VOL —	Vol -
MUTE	Mute	MUTE	Mute
REMAIN	Remain	HOME SMART	Smart
TUNING /CH	Tuning+ / CH+	CH +	Ch +

Original		Replacement		Original		Replacement	
TUNING /CH	Tuning- / CH-	CH –	Ch -		Up		Up
MENU	Menu	TOP MENU MENU	Menu		Left		Left
RETURN	Return	RETURN BACK	Back	ENTER	Enter	OK	Ok
INFO	Info	DISPLAY INFO	Info		Right		Right
EXIT	Exit	CLEAR EXIT	Exit		Down		Down
TUNER MEMORY	Tuner Memory	A	Red				
MO/ST	Mo / St	B	Green				
P.BASS	P. Bass	SETTINGS OPT	Options				
SOUND EDIT	Sound Edit	SHIFT + SOUND DUAL	Shift + Dual				
LOGO	Logo	ECO 3D	3D				
DIMMER	Dimmer	SHIFT + MUTE	Shift + Mute				
SLOW	Slow	SHIFT +	Shift + Left				
REPEAT	Repeat	REPEAT TEXT	Text				
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject				
CD RIPPING	CD Ripping	REC MODE	Rec				
CANCEL	Cancel	SHIFT + CLEAR EXIT	Shift + Exit				
SLEEP	Sleep	PROG SLEEP	Sleep				

Original		Replacement	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
MENU	Menu	TOP MENU MENU	Menu
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SOURCE	Source	TIMER AV	AV
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
TUNING /CH	CH+	CH +	Ch +

Original		Replacement	
TUNING /CH	CH-	CH −	Ch -
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
INFO	Info	DISPLAY INFO	Info