Mandis shop

RBUB1470

Original		Replacement	
⏻/ON	Standby/on	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
TUN/BAND	Tun/Band	APP MEDIA	Media
TIMER/CLOCK	Timer/Clock	SETTINGS OPT	Options
UNING ▲	Folder/Tuning Up	+ CH	Ch +
FOLDE ▼	Folder/Tuning	CH −	Ch -
FM MODE	FM Mode	A	Red
STOP ■	Stop	■	Stop
USB/SD ▶/II	Play/Pause	II	Pause
CD ▶/II	Play/Pause CD	PLAY MODE ▶	Play
ET ⏭ ^	Up/Preset >>I	⏭	>>I
⏮ PR ∨	Down/I<<	⏮	I<<
TAPE/AUX	Tape/AUX	B	Green
REPEAT	Repeat	REPEAT TEXT	Text
RANDOM	Random	TIMER AV	AV
MEMORY/DISPLAY	Memory/Display	TOP MENU MENU	Menu
+	Vol+	+ VOL	Vol +

Original		Replacement	
−	Vol-	VOL −	Vol -
SOUND	Sound	SOUND DUAL	Dual
BASS	Bass	AD SUBT	Subt
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	-/-- GUIDE	Guide

https://mandos-a-distancia.es/en/Sanyo/1038929-79042-replacement-remote-control-for-Sanyo-RB-UB1470-6450942563.html