Mandis shop

VRM-60

Original		Replacement		Original		Replacement	
ON/OFF	On/Off		Power				
CHANNEL >	Channel >	CH PAGE +	CH+ / Page+				
CHANNEL <	< Channel	CH PAGE −	CH- / Page-				
PLAY	Play	SLOW	Play / Slow				
STOP	Stop	HOLD	Stop / Hold				
PAUSE STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze				
F FWD	>>/F.FWD	TUNE+	>> / Tune+				
REW	<</Rew	TUNE-	<< / Tune-				
REC	Rec	REC MODE	Rec / Rec Mode				

https://mandos-a-distancia.es/en/Sanyo/1067231-96924-replacement-remote-control-for-Sanyo-VRM-60.html