Mandis shop

# Sony RM-S171

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Display | | Info |
| | DSG | | Eject |
| | Play CD | | Play |
| | Pause CD | | Pause |
| | Stop CD | | Stop |
| | Play | SHIFT + PLAY MODE | Shift + Play |
| | I<</- Tuner | | I<< |
| | >>I/+ Tuner | | >>I |
| | Play/<> Tape | | Options |
| | << Tape | | << |
| | >> Tape | | >> |
| | Play Dir Mode | | Smart |
| | FM Mode | | Dual |
| | Rec | | Rec |
| | CD Repeat | | Text |
| | Function | | Menu |

| Original | | Replacement | |
|---|---|---|---|
| | Tuning Mode/Play Mode | | Format |
| | Up/Memory | | Up |
| | Down/Sleep | | Down |
| | Right/Timer | | Right |
| | Left/Timer Set | | Left |
| | Enter/On/Off | | Ok |
| | Vol+ | | Vol + |
| | Vol- | | Vol - |

https://mandos-a-distancia.es/en/Sony/1058653-5964-replacement-remote-control-for-Sony-RM-S171-147723911.html