Original		Replacement	
TV/VIDEO I/⏻	Standby TV	⏻	Power
TV/VIDEO SLEEP	Tv/Video TV	SEARCH TV/R	TV/R
TV CH + PRESET +	CH+ TV	+ CH	Ch +
TV CH − PRESET −	CH- TV	CH −	Ch -
TV VOL MASTER VOL +	Vol + TV	+ VOL	Vol +
−	Vol - TV	VOL −	Vol -
1	1 TV	1	1
2	2 TV	2	2
3	3 TV	3	3
4	4 TV	4	4
5	5 TV	5	5
6	6 TV	6	6
7	7 TV	7	7
8	8 TV	8	8
9	9 TV	9	9
0/10	0/10 TV	0	0
>10 -/-- CLEAR	-/-- TV	-/-- GUIDE	Guide

Original		Replacement	
MEMORY D.SKIP	Enter/Memory/D.Skip TV	FAV PRE-CH	Pre Ch
AV I/⏻	Standby AV Video	SHIFT + ⏻	Shift + Power
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	APP MEDIA	Media
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
TEST TONE	Test Tone	HOME SMART	Smart
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
MAIN MENU	Main Menu	TOP MENU MENU	Menu
FM MODE MPX AUDIO	MPX/FM Mode/Audio Video	SHIFT + SEARCH TV/R	Shift + TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Video 1	AD SUBT	Subt

Original	Replacement	Original	Replacement
Enter/Memory/D.Skip Video 1	SHIFT + PRE-CH Shift + Pre Ch	Enter Video 1	OK Ok
1 Video 1	SHIFT + 1 Shift + 1	Display Video	DISPLAY INFO Info
2 Video 1	SHIFT + 2 Shift + 2	Master Vol +	SHIFT + VOL + Shift + Vol +
3 Video 1	SHIFT + 3 Shift + 3	Master Vol -	SHIFT + VOL – Shift + Vol -
4 Video 1	SHIFT + 4 Shift + 4	Muting	MUTE Mute
5 Video 1	SHIFT + 5 Shift + 5	Play Video 1	PLAY MODE Play
6 Video 1	SHIFT + 6 Shift + 6	Pause Video 1	Pause
7 Video 1	SHIFT + 7 Shift + 7	Stop Video 1	Stop
8 Video 1	SHIFT + 8 Shift + 8	<<Tuning- Video	<<
9 Video 1	SHIFT + 9 Shift + 9	>>Tuning+	>>
0/10 Video 1	SHIFT + 0 Shift + 0	I<<Preset+	I<<
-/--/>10/Clear Video 1	SHIFT + GUIDE Shift + Guide	>>I/Preset + Video 1	>>I
AV Menu Video	TIMER AV AV	→Advance/Step I> Video 1	SHIFT + CH + Shift + Ch +
Up Video 1	Up	←/Replay/<I Step Video 1	SHIFT + CH – Shift + Ch -
Down Video 1	Down		
Right Video 1	Right		
Left Video 1	Left		

Original		Replacement	
	Standby System		Power
	Standby AV	SHIFT +	Shift + Power
	Sleep	PROG SLEEP	Sleep
	Test Tone	HOME SMART	Smart
	Play	PLAY MODE	Play
	>>/ Tuning+		>>
	<</ Tuning-		<<
	Pause		Pause
	Stop		Stop
	Main Menu	TOP MENU MENU	Menu
	Video 1	A	Red
	Video 2	B	Green
	SA-CD/CD	C	Yellow
	DVD	D	Blue
	Tuner	APP MEDIA	Media
	1	1	1
	2	2	2

Original		Replacement	
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0/10	0	0
	-/--/>10/Clear	-/-- GUIDE	Guide
	Enter/Memory/D.S	FAV PRE-CH	Pre Ch
	Top	SHIFT + TOP MENU MENU	Shift + Menu
	AV Menu	TIMER AV	AV
	Muting	MUTE	Mute
	Return/Exit	RETURN BACK	Back
	Display	DISPLAY INFO	Info
	Master Vol +	+ VOL	Vol +
	Master Vol -	VOL −	Vol -

Original		Replacement		Original	Replacement
TV CH – PRESET –	I <</ Preset -	K<	I <<		
TV CH + PRESET +	>>I / Preset +	>>I	>>I		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
ENTER	Enter	OK	Ok		
EP ADVANCE	· →Advance/ Step I >	+ CH	Ch +		
REPLAY	← / Replay/ ◁ I Step	CH –	Ch -		
MUSIC	Music	SOUND DUAL	Dual		
MOVIE	Movie	PICTURE FORMAT	Format		
A.F.D.	A. F. D.	SETTINGS OPT	Options		
DUAL MONO	Dual Mono	ECO 3D	3D		
2CH	2CH	REPEAT TEXT	Text		
FM MODE AUDIO	MPX/ FM	SEARCH TV/R	TV/ R		
D.TUNING SUBTITLE	ANT/ D. Tuning/ Subtitle	AD SUBT	Subt		
SHIFT ANGLE	Jump/ Shift/ Angle	DISC NAV LIST	List		

Original		Replacement	
	Standby System		Power
	Standby AV	SHIFT +	Shift + Power
	Sleep	PROG SLEEP	Sleep
	Test Tone	HOME SMART	Smart
	Video 1	A	Red
	Video 2	B	Green
	SA-CD/CD	C	Yellow
	DVD	D	Blue
	Tuner	APP MEDIA	Media
	Main Menu	TOP MENU MENU	Menu
	Music	SOUND DUAL	Dual
	Movie	PICTURE FORMAT	Format
	2CH	REPEAT TEXT	Text
	Dual Mono	ECO 3D	3D
	A. F. D.	SETTINGS OPT	Options
	Enter/Memory/D. S	FAV PRE-CH	Pre Ch
	1	1	1

Original		Replacement	
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0/10	0	0
	-/--/>10/Clear	-/-- GUIDE	Guide
	Master Vol +	+ VOL	Vol +
	Master Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Display	DISPLAY INFO	Info
	Enter	OK	Ok
	Play	PLAY MODE ▶	Play
	Pause	II	Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
TUNING –	<<Tuning-		<<		
TUNING +	>>Tuning+		>>		
TV CH – PRESET –	I<<Preset-		I<<		
TV CH + PRESET +	>>I / Preset+		>>I		

Original		Replacement	
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	HOME SMART	Smart
SLEEP	Sleep	PROG SLEEP	Sleep
Standby System			Power
MAIN MENU	Main Menu	TOP MENU MENU	Menu
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
FM MODE MPX AUDIO	MPX/FM Mode/Audio Tuner	SEARCH TV/R	TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Tuner	AD SUBT	Subt
SHIFT ANGLE	Jump/Shift/Angle Tuner	DISC NAV LIST	List
1	1 Tuner	1	1

Original		Replacement	
2	2 Tuner	2	2
3	3 Tuner	3	3
4	4 Tuner	4	4
5	5 Tuner	5	5
6	6 Tuner	6	6
7	7 Tuner	7	7
8	8 Tuner	8	8
9	9 Tuner	9	9
0/10	0/10 Tuner	0	0
MEMORY ENTER D.SKIP	Enter/Memory/D.Skip Tuner	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Master Vol +	+ VOL	Vol +
–	Master Vol -	VOL –	Vol -
DISPLAY	Display Tuner	DISPLAY INFO	Info
TV CH – PRESET –	I<<Preset- Tune	I<<	I<<
TV CH + PRESET +	>>I/Preset+	>>I	>>I
TUNING –	<<Tuning- Tuner	<<	<<

Original	Replacement
>>/ Tuning+	>>
Test Tone	Media
Standby Video	Shift + Power
MPX/ FM Mode/ Audio Video	Shift + TV/ R
ANT/ D. Tuning/ Subtitle Video 2	Shift + Subt
Enter/ Memory/ D. Skip Video 2	Shift + Pre Ch
1 Video 2	Shift + 1
2 Video 2	Shift + 2
3 Video 2	Shift + 3
4 Video 2	Shift + 4
5 Video 2	Shift + 5
6 Video 2	Shift + 6
7 Video 2	Shift + 7
8 Video 2	Shift + 8
9 Video 2	Shift + 9
0/ 10 Video 2	Shift + 0
-/ --/ >10/ Clear Video 2	Guide

Original	Replacement
AV Menu Video	AV
Up Video 2	Up
Down Video 2	Down
Right Video 2	Right
Left Video 2	Left
Enter Video 2	Ok
Display Video	Shift + Info
Play Video 2	Play
Pause Video 2	Pause
Stop Video 2	Stop
← / Replay/ ◁ I Step Video 2	Ch -
· →Advance/ Step I > Video 2	Ch +
>>I / Preset+	Shift + >>I
I <</ Preset- Vide	Shift + I <<
>>/ Tuning+	Shift + >>
<</ Tuning- Video	Shift + <<