Mandis shop

RM-ST1

Original		Replacement	
TIMER SELECT	Timer Select	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SYSTEM POWER	System Power		Power
TIMER SET	Timer Set	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
– TIMI	Timer-	CH PAGE –	CH- / Page-
MER +	Timer+	+ CH PAGE	CH+ / Page+
	Play CD/Tuner	SLOW ▶	Play / Slow
	Pause CD/Tuner	STEP - FREEZE ❚❚	Pause / Step / Freeze
	Stop CD/Tuner	SHIFT + HOLD ■	Shift + Stop /
BAND	Band CD/Tuner	CD - STB 3	3
– TUN	I<<Tuning- CD/Tuner	PRESET- ⏮	I<< / Preset-
NING +	>>I/Tuning+ CD/Tuner	PRESET+ ⏭	>>I / Preset+
STEREO/ MONO	Stereo/Mono CD/Tuner	TITLE SOUND	Sound / Title
TUNING/ PLAY MODE	Tuning/Play Mode CD/Tuner	TAPE 5	5
REPEAT	Repeat	RETURN BACK	Back / Return
DISPLAY	Display CD/Tuner	MEDIA DISPLAY	Display / Media
MEMORY	Memory	TUNER 6	6

Original		Replacement	
ENTER	Enter	OK	OK
	< Tape	SHIFT + TUNE- ◀◀	Shift + << /
	> Tape	SHIFT + TUNE+ ▶▶	Shift + >> /
	Stop Tape	HOLD ■	Stop / Hold
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
	<< Tape	TUNE- ◀◀	<< / Tune-
	>> Tape	TUNE+ ▶▶	>> / Tune+
DBFB	DBFB	DVD 2	2
SURROUND	Surround	SURROUND ⏏	Eject / Surround
+ VOL	Vol+	+ VOL	Vol+
BALAN L	Balance L	◀	Left
ANCE R	Balance R	▶	Right
VOL –	Vol-	VOL –	Vol-

CD/Tuner

https://mandos-a-distancia.es/en/Sony/1059504-85143-replacement-remote-control-for-Sony-RM-ST1.html