Mandis shop

Sony RM-S130

Original		Replacement	
+	Vol +	VOL +	Vol +
–	Vol -	VOL –	Vol -
▶	Play CD	PLAY MODE ▶	Play
❚❚	Pause CD	❚❚	Pause
■	Stop CD	■	Stop
⏮	I<< CD	⏮	I<<
⏭	>>I CD	⏭	>>I
DISC SKIP	Disc Skip CD	HOME SMART	Smart
+ PRESET	Tuner Preset +	CH +	Ch +
PRESET –	Tuner Preset -	CH –	Ch -
TAPE	Function Tape	1	1
TUNER	Function Tuner	2	2
CD	Function CD	3	3
PHONO	Function Phono	4	4

Original	Replacement

https://mandisdistance.com/Sony-10329-197-replacement-remote-control-for-Sony-RM-S130-1633811.htm