Original		Replacement	
	Power		Power
	Input	TIMER AV	AV
TV/ RADIO	Tv/Radio	SEARCH TV/R	TV/R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
DIGITAL/ ANALOG	Digital/Analog	PICTURE FORMAT	Format
EXIT	Exit	CLEAR EXIT	Exit
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
	[i+]/[?]	DISPLAY INFO	Info

Original		Replacement	
	[=]	REPEAT TEXT	Text
Google Play	Google Play	SHIFT + HOME SMART	Shift + Smart
NETFLIX	Netflix	APP MEDIA	Media
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
TV	TV	ECO 3D	3D
GUIDE	Guide	-/-- GUIDE	Guide
ACTION MENU	Action Menu	E-MANUAL D.MENU	D. Menu
DISCOVER	Discover	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
HOME	Home	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
PROG +	Prog+	+ CH	Ch +
	Recall	FAV PRE-CH	Pre Ch
–	Prog-	CH –	Ch -
AUDIO	Audio	SOUND DUAL	Dual
	<<	<<	<<
	Play	PLAY MODE	Play
	>>	>>	>>
	I <<	I <<	I <<
	Pause	Pause	Pause
	>>I	>>I	>>I
REC	Rec	REC MODE	Rec
	Stop	Stop	Stop
TITLE LIST	Title List	DISC NAV LIST	List

Original		Replacement	
HELP	Help	ZOOM	Eject
	[. . .]	AD SUBT	Subt