Mandis shop

# Tcl MA06405001267RC1

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| AUX | Aux | 7 | 7 |
| BT | BT | 9 | 9 |
| USB | USB | 8 | 8 |
| OPTICAL | Optical | SETUP | Setup / OPT / |
| HDMI IN | HDMI IN | AUDIO | Audio / Lang I/II |
| HDMI ARC | HDMI ARC | SUBTITLE | Subtitle / EQ |
| | I<< | | I<< / Preset- |
| ▶II/OK | Play/Pause/OK | OK | OK |
| | >>I | | >>I / Preset+ |
| BASS + | Bass+ | VOL + | Vol+ |
| BASS − | Bass- | VOL − | Vol- |
| + | + | | Up |
| − | - | | Down |
| TREBLE + | Treble+ | CH PAGE + | CH+ / Page+ |
| TREBLE − | Treble- | CH PAGE − | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Replacement | |
|---|---|---|---|
| VERTICAL SURROUND | Vertical Surround | LIST SMART | Smart / List |
| SOUND MODE | Sound Mode | MEDIA DISPLAY | Display / Media |
| AV SYNC − | AV Sync- | FORMAT PICTURE | Picture / Format |
| AV SYNC + | AV Sync+ | SIZE ZOOM | Zoom / Size |

https://mandos-a-distancia.es/en/Tcl/1065429-95471-replacement-remote-control-for-Tcl-MA06405001267RC1.html