Original		Replacement	
	Power MD		Power
	TV	SEARCH TV/R	TV/R
	CD	C	Yellow
	DVD	D	Blue
	Tuner/Band	B	Green
	Tape	A	Red
	VCR	HOME SMART	Smart
	MD	APP MEDIA	Media
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Stop MD	■	Stop
	Play MD	PLAY MODE ▶	Play
	<</I<< MD	«	<<
	>>/>>I MD	»	>>
	Up	▲	Up
	Down	▼	Down

Original		Replacement	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
1	1 MD	1	1
2	2 MD	2	2
3	3 MD	3	3
4	4 MD	4	4
5	5 MD	5	5
6	6 MD	6	6
7	7 MD	7	7
8	8 MD	8	8
9	9 MD	9	9
0	0 MD	0	0
≥10/-/--	>10/-/-- MD	-/-- GUIDE	Guide

Original		Replacement	
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
Power TV		SHIFT + Power	Shift + Power
TV VOL ^	Tv Vol Up	SHIFT + VOL +	Shift + Vol +
TV VOL v	Tv Vol Down	SHIFT + VOL -	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5

Original		Replacement	
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original	Replacement	Original	Replacement
Power DVD	Power	Right	Right
TV	TV/R	Left	Left
VCR	Smart	Enter	Ok
Tuner/Band	Green	Stereo	Dual
Tape	Red	Surround	Options
MD	Media	SFC	Subt
CD	Yellow	Test	Back
DVD	Blue	Delay	Format
Play DVD	Play	Level	3D
I <</ << DVD	<<	+	Ch +
Stop DVD	Stop	-	Ch -
>>/ >>I DVD	>>	1 DVD	1
Top Menu/Disc/Deck	Menu	2 DVD	2
Display	Info	3 DVD	3
Menu	D. Menu	4 DVD	4
Up	Up	5 DVD	5
Down	Down	6 DVD	6

Original		Replacement		Original	Replacement
7	7 DVD	7	7		
8	8 DVD	8	8		
9	9 DVD	9	9		
0	0 DVD	0	0		
≥10/-/--	>10/ - / - - DVD	-/-- GUIDE	Gui de		
VOL +	Vol +	+ VOL	Vol +		
– VOL	Vol -	VOL –	Vol -		
MUTING	Mut i ng	MUTE	Mut e		

Original		Replacement	
	Power CD		Power
	TV		TV/R
	VCR		Smart
	CD		Yellow
	DVD		Blue
	Tape		Red
	MD		Media
	Tuner/Band		Green
	Stop CD		Stop
	I<</<< CD		<<
	>>/>>I CD		>>
	Play CD		Play
	Menu		D. Menu
	Display		Info
	Top Menu/Disc/Deck		Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
	Enter		Ok
	Stereo		Dual
	Surround		Options
	SFC		Subt
	Test		Back
	Delay		Format
	Level		3D
	+		Ch +
	-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Muting		Mute
	Power Tape		Shift + Power
	Stop Tape		Shift + Stop
	Play Tape		Shift + Play

Original		Replacement		Original	Replacement
I <</ << Tape		SHIFT + <<	Shift + <<		
>>/ >>I Tape		SHIFT + >>	Shift + >>		
Top Menu/ Disc/ Deck		SHIFT + TOP MENU / MENU	Shift + Menu		
1 CD- Tape		1	1		
2 CD- Tape		2	2		
3 CD- Tape		3	3		
4 CD- Tape		4	4		
5 CD- Tape		5	5		
6 CD- Tape		6	6		
7 CD- Tape		7	7		
8 CD- Tape		8	8		
9 CD- Tape		9	9		
0 CD- Tape		0	0		
>10/ - / - - CD- Tape		-/-- GUIDE	Guide		
Direct Tuning/ Disc Ente		REPEAT TEXT	Text		

Original	Replacement	Original	Replacement
Power VCR	Power	6 VCR	6
VCR	Smart	7 VCR	7
Tape	Red	8 VCR	8
TV	TV/ R	9 VCR	9
CD	Yellow	0 VCR	0
DVD	Blue	>10/ - / - - VCR	Guide
Tuner / Band	Green	Direct Tuning/ Disc Ente	Text
MD	Media	Vol +	Vol +
Stop	Stop	Vol -	Vol -
I <</ <<	<<	Muting	Mute
>>/ >>I	>>	Up	Up
Play	Play	Down	Down
1 VCR	1	Right	Right
2 VCR	2	Left	Left
3 VCR	3	Enter	Ok
4 VCR	4	Top Menu/ Disc/ Deck	Menu
5 VCR	5	Display	Info

Original	Replacement
Menu	D. Menu
Stereo	Dual
Surround	Options
SFC	Subt
Test	Back
Delay	Format
Level	3D
+	Ch +
-	Ch -
Power Tuner/Band	Shift + Power
1 Tuner/Band	Shift + 1
2 Tuner/Band	Shift + 2
3 Tuner/Band	Shift + 3
4 Tuner/Band	Shift + 4
5 Tuner/Band	Shift + 5
6 Tuner/Band	Shift + 6
7 Tuner/Band	Shift + 7

Original	Replacement
8 Tuner/Band	Shift + 8
9 Tuner/Band	Shift + 9
0 Tuner/Band	Shift + 0
>10/-/--	Shift + Guide