Mandis shop

EUR64754

Original	Replacement	Original	Replacement
On/Off	Power	Play > Tape	Right
1	1	Stop Tape	OK
2	2	Pause Tape	Down
3	3	<< Tape	<< / Tune-
4	4	>> Tape	>> / Tune+
5	5	Auto Rec Mute	Up
6	6	Rec Tape	Rec / Rec Mode
7	7	< Start Turntabl	Menu / Home
8	8	EQ On/Flat	Smart / List
9	9	EQ On/Flat	Subtitle / EQ
0	0	EQ Preset	Display / Media
Play/Pause CD	Play / Slow	Stop Turntable	Exit / Cancel / Clear
Play/Pause CD	Pause / Step / Freeze	Muting/-20dB	Mute / Dimmer
Stop CD	Stop / Hold	Volume Down	Vol -
I<< Skip/Search	I<< / Preset-	Volume Up	Vol +
Skip/Search >>I	>>I / Preset+		
< Play Tape	Left		

https://mandisdistance.com/Technics/1665-968-replacement-remote-control-for-Technics-EUR64754.htm