Original	Replacement	Original	Replacement
Power TV	Power	Up TV	Up
Mute TV TV	Mute / Dimmer	Left/RDS TV	Left
Play/Save TV	Play / Slow	OK TV	OK
Pause TV	Pause / Step / Freeze	Right/PTY TV	Right
Stop TV	Stop / Hold	Clear TV	Exit / Cancel / Clear
Rec TV	Rec / Rec Mode	Down TV	Down
<</Tuner- TV	<< / Tune-	Back/ST-Mono	Back / Return
>>/Tuner+ TV	>> / Tune+	Vol + TV TV	Vol +
PR-/I<< TV	I<< / Preset-	PR+/>>I TV	CH+ / Page+
PR+/>>I TV	>>I / Preset+	Vol - TV TV	Vol -
Level TV	Sound / Title	PR-/I<< TV	CH- / Page-
Subwoofer TV	Audio / Lang I/II	1 Tv	1
Equalizer TV	Subtitle / EQ	2 TV	2
Surround TV	Eject / Surround	3 TV	3
Night TV	Sleep / Timer	4 TV	4
Setup TV	Setup / OPT /	5 TV	5
Menu TV TV	Menu / Home	6 TV	6

Original	Replacement
7 TV	7
8 TV	8
9 TV	9
Guide TV	Guide / EPG / -/--
0 TV	0
Tape-CD	Red / Netflix / Search
AUX1 (VCR)	Green / APP / Repeat
Aux2 (SAT-Cable	Yellow / YouTube / Repeat
Power AUX1	Shift + Power
Play/Save AUX1	Shift + Play /
Pause AUX1	Shift + Pause / Step /
Stop AUX1	Shift + Stop /
Rec AUX1	Shift + Rec / Rec Mode
<</Tuner-	Shift + << /
>>/Tuner+	Shift + >> /
PR-/I <<AUX1	Shift + I<< / Preset-
PR+/ >>I AUX1	Shift + >>I / Preset+

Original	Replacement
Up AUX1	Shift + Up
Left/RDS AUX1	Shift + Left
OK AUX1	Shift + OK
Right/PTY AUX1	Shift + Right
Down AUX1	Shift + Down
PR+/ >>I AUX1	Shift + CH+ /
PR-/I <<AUX1	Shift + CH- /
1 AUX1	Shift + 1
2 AUX1	Shift + 2
3 AUX1	Shift + 3
4 AUX1	Shift + 4
5 AUX1	Shift + 5
6 AUX1	Shift + 6
7 AUX1	Shift + 7
8 AUX1	Shift + 8
9 AUX1	Shift + 9
Guide AUX1	Shift + Guide / EPG / -/--

Original	Replacement	Original	Replacement
0 AUX1	SHIFT + HDMI - SAT 0	Shift + 0	

Original	Replacement	Original	Replacement
Power DVD6CH	Power	Up DVD6CH	Up
Mute DVD6CH	Mute / Dimmer	Left/RDS	Left
Play/Save	Play / Slow	OK DVD6CH	OK
Pause DVD6CH	Pause / Step / Freeze	Right/PTY	Right
Stop DVD6CH	Stop / Hold	Clear DVD6CH	Exit / Cancel / Clear
Rec DVD6CH	Rec / Rec Mode	Down DVD6CH	Down
<</Tuner-	<< / Tune-	Back/St-Mono	Back / Return
>>/Tuner+	>> / Tune+	Vol + DVD6CH	Vol +
PR-/I <<	I << / Preset-	PR+/ >>I	CH+ / Page+
PR+/ >>I	>>I / Preset+	Vol - DVD6CH	Vol -
Level DVD6CH	Sound / Title	PR-/I <<	CH- / Page-
Subwoofer	Audio / Lang I/II	1 DVD6CH	1
Equalizer	Subtitle / EQ	2 DVD6CH	2
Surround	Eject / Surround	3 DVD6CH	3
Night DVD6CH	Sleep / Timer	4 DVD6CH	4
Setup DVD6CH	Setup / OPT /	5 DVD6CH	5
Menu DVD6CH	Menu / Home	6 DVD6CH	6

Original	Replacement	Original	Replacement
7 DVD6CH	7	Up Tape- CD	Shift + Up
8 DVD6CH	8	Left / RDS Tape- CD	Shift + Left
9 DVD6CH	9	OK Tape- CD	Shift + OK
Gui de DVD6CH	Gui de / EPG / -/--	Ri ght / PTY	Shift + Ri ght
0 DVD6CH	0	Down Tape- CD	Shift + Down
Tape- CD	Red / Netflix / Search	Back/ ST- Mono Tape- CD	Shift + Back / Return
AUX1 (VCR)	Green / APP / Repeat	PR+/ >>I	Shift + CH+ /
Aux2 (SAT- Cabl e	Yel l ow / YouTube / Repeat	PR- / I <<	Shift + CH- /
Power Tape- CD	Shi ft + Power	1 Tape- CD	Shift + 1
Pl ay/ Save	Shi ft + Pl ay /	2 Tape- CD	Shift + 2
Pause Tape- CD	Shi ft + Pause / Step /	3 Tape- CD	Shift + 3
St op Tape- CD	Shi ft + Stop /	4 Tape- CD	Shift + 4
Rec Tape- CD	Shi ft + Rec / Rec Mode	5 Tape- CD	Shift + 5
<</ Tuner-	Shi ft + << /	6 Tape- CD	Shift + 6
>>/ Tuner +	Shi ft + >> /	7 Tape- CD	Shift + 7
PR- / I <<	Shi ft + I << / Preset-	8 Tape- CD	Shift + 8
PR+/ >>I	Shi ft + >>I / Preset+	9 Tape- CD	Shift + 9

Tape- CD

Original	Replacement	Original	Replacement
0 Tape-CD	SHIFT + HDMI-SAT 0	Shift + 0	

Original	Replacement
Power TUNER	Power
Mute TUNER	Mute / Dimmer
Play/Save	Play / Slow
Pause TUNER	Pause / Step / Freeze
Stop TUNER	Stop / Hold
<</Tuner-	<< / Tune-
>>/Tuner+	>> / Tune+
PR-/I<< TUNER	I<< / Preset-
PR+/>>I TUNER	>>I / Preset+
Level TUNER	Sound / Title
Subwoofer	Audio / Lang I/II
Equalizer	Subtitle / EQ
Surround	Eject / Surround
Night TUNER	Sleep / Timer
Setup TUNER	Setup / OPT /
Menu TUNER	Menu / Home
Up TUNER	Up

Original	Replacement
Left/RDS TUNER	Left
OK TUNER	OK
Right/PTY	Right
Clear TUNER	Exit / Cancel / Clear
Down TUNER	Down
Back/St-Mono	Back / Return
Vol + TUNER	Vol +
PR+/>>I TUNER	CH+ / Page+
Vol - TUNER	Vol -
PR-/I<< TUNER	CH- / Page-
1 TUNER	1
2 TUNER	2
3 TUNER	3
4 TUNER	4
5 TUNER	5
6 TUNER	6
7 TUNER	7

Original	Replacement	Original	Replacement
8 TUNER	8	Up AUX2	Shift + Up
9 TUNER	9	Left / RDS AUX2	Shift + Left
Guide TUNER	Guide / EPG / -/--	OK AUX2	Shift + OK
0 TUNER	0	Right / PTY AUX2	Shift + Right
Tape- CD	Red / Netflix / Search	Clear AUX2	Shift + Exit / Cancel / Clear
AUX1 (VCR)	Green / APP / Repeat	Down AUX2	Shift + Down
Aux2 (SAT- Cable	Yellow / YouTube / Repeat	Back/ St- Mono	Shift + Back / Return
Power AUX2	Shift + Power	PR+/ >>I AUX2	Shift + CH+ /
Play/ Save AUX2	Shift + Play /	PR- / I << AUX2	Shift + CH- /
Pause AUX2	Shift + Pause / Step /	1 AUX2	Shift + 1
Stop AUX2	Shift + Stop /	2 AUX2	Shift + 2
Rec AUX2	Shift + Rec / Rec Mode	3 AUX2	Shift + 3
<</ Tuner-	Shift + << /	4 AUX2	Shift + 4
>>/ Tuner +	Shift + >> /	5 AUX2	Shift + 5
PR- / I << AUX2	Shift + I<< / Preset-	6 AUX2	Shift + 6
PR+/ >>I AUX2	Shift + >>I / Preset+	7 AUX2	Shift + 7
Menu AUX2	Shift + Menu / Home	8 AUX2	Shift + 8

Original	Replacement	Original	Replacement
9 AUX2	SHIFT + 9		
Guide AUX2	SHIFT + GUIDE EPG		
0 AUX2	SHIFT + 0		