Original	Replacement	Original	Replacement
Power	Power	Left	Left
CD	SHIFT + CD-STB 3 Shift + 3	OK	OK
Tape	SHIFT + TAPE 5 Shift + 5	Vol +	VOL + Vol +
Tuner	SHIFT + TUNER 6 Shift + 6	Vol -	VOL − Vol -
VID 1	SHIFT + TV 1 Shift + 1	PR+	CH PAGE + CH+ / Page+
VID 2	SHIFT + DVD 2 Shift + 2	PR-	CH PAGE − CH- / Page-
VID 3	SHIFT + VIDEO 4 Shift + 4	Mute	DIMMER MUTE Mute / Dimmer
Red/ Format	NETFLIX SEARCH Red / Netflix / Search	1	TV 1 1
Green/ Sound	APP REPEAT Green / APP / Repeat	2	DVD 2 2
Yellow/ [ ]	YouTube REPEAT A-B Yellow / YouTube / Repeat	3	CD-STB 3 3
Blue/ Timer	Prime Video RANDOM Blue / Prime Video / Random	4	VIDEO 4 4
Violet/ PC	PROGRAM TV/ RADIO TV/ Radio /	5	TAPE 5 5
Exit	CLEAR EXIT CANCEL Exit / Cancel / Clear	6	TUNER 6 6
Menu	HOME MENU Menu / Home	7	AUX-HDD 7 7
Up	Up	8	USB 8 8
Down	Down	9	BLUETOOTH 9 9
Right	Right	0/--	HDMI-SAT 0 0

Original	Replacement	Original	Replacement
AV	AV / Input / RDS		
<</ REW	<< / Tune-		
Play	Play / Slow		
>>/ F. FWD	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
1	1	Exit	Exit / Cancel / Clear
2	2	Up	Up
3	3	Down	Down
4	4	Left	Left
5	5	Right	Right
6	6	OK	OK
7	7	Red/ Format	Red / Netflix / Search
8	8	Green/ Sound	Green / APP / Repeat
9	9	Yellow/ [ ]	Yellow / YouTube / Repeat
0/ - -	0	Blue/ Timer	Blue / Prime Video / Random
AV	AV / Input / RDS	Violet / PC	TV/ Radio /
Mute	Mute / Dimmer	Stop	Stop / Hold
Vol +	Vol +	Pause	Pause / Step / Freeze
Vol -	Vol -	CD	Shift + 3
PR+	CH+ / Page+	VID 1	Eject / Surround
PR-	CH- / Page-	Tape	Shift + 5

Original	Replacement	Original	Replacement
VID 2	EQ SUBTITLE Subtitle / EQ		
Tuner	SHIFT + TUNER 6 Shift + 6		
VID 3	RETURN BACK Back / Return		
Play	SLOW Play / Slow		
>>/ F. FWD	TUNE+ >> / Tune+		
<</ REW	TUNE- << / Tune-		
Rec	REC MODE Rec / Rec Mode		

Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
1	1	Exit	Exit / Cancel / Clear
2	2	Down	Down
3	3	Up	Up
4	4	Left	Left
5	5	Right	Right
6	6	OK	OK
7	7	Red/ Format	Red / Netflix / Search
8	8	Green/ Sound	Green / APP / Repeat
9	9	Yellow/ [ ]	Yellow / YouTube / Repeat
0/ - -	0	Blue/ timer	Blue / Prime Video / Random
AV	AV / Input / RDS	Violet / PC	TV/ Radio /
Mute	Mute / Dimmer	Stop	Stop / Hold
Vol +	Vol +	Pause	Pause / Step / Freeze
Vol -	Vol -	Play	Play / Slow
PR+	CH+ / Page+	>>/ F. FWD	>> / Tune+
PR-	CH- / Page-	<</ REW	<< / Tune-

Original	Replacement	Original	Replacement
Rec	REC MODE Rec / Rec Mode		
CD	SHIFT + CD-STB 3 Shift + 3		
VID 1	SURROUND Eject / Surround		
Tape	SHIFT + TAPE 5 Shift + 5		
VID 2	EQ SUBTITLE Subtitle / EQ		
Tuner	SHIFT + TUNER 6 Shift + 6		
VID 3	RETURN BACK Back / Return		

Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
1	1	Exit	Exit / Cancel / Clear
2	2	OK	OK
3	3	Up	Up
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Red/ Format	Red / Netflix / Search
8	8	Green/ Sound	Green / APP / Repeat
9	9	Yellow/ [ ]	Yellow / YouTube / Repeat
0/ - -	0	Blue/ Timer	Blue / Prime Video / Random
AV	AV / Input / RDS	Violet / PC	TV/ Radio /
Mute	Mute / Dimmer	Play	Play / Slow
Vol +	Vol +	>>/ F. FWD	>> / Tune+
Vol -	Vol -	<</ REW	<< / Tune-
PR+	CH+ / Page+	Rec	Rec / Rec Mode
PR-	CH- / Page-	Stop	Stop / Hold

Original	Replacement	Original	Replacement
Pause	STEP-FREEZE II Pause / Step / Freeze		
CD	SHIFT + CD-STB 3 Shift + 3		
VID 1	SURROUND ⏏ Eject / Surround		
Tape	SHIFT + TAPE 5 Shift + 5		
VID 2	EQ SUBTITLE Subtitle / EQ		
Tuner	SHIFT + TUNER 6 Shift + 6		
VID 3	RETURN BACK Back / Return		