Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Lang		Dual
	[≡] . . .		Subt
	V+		Vol +
	V-		Vol -
	Mute		Mute
	Voice		Shift + Smart

Original		Replacement	
	P+		Ch +
	P-		Ch -
	Home		Smart
	[G]		Guide
	i		Info
	←		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Netflix		Media
	FPay		Shift + Media
	Menu		Menu
	Source		AV
	Red		Red

Original		Replacement	
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<		<<
	Stop		Stop
	>>		>>
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
TEXT	Text	REPEAT TEXT	Text

Original	Replacement