Original		Replacement	
POWER	Power		Power
TV/AV	Tv/AV	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
EJECT	Eject	ZOOM	Eject
PLAY/PAUSE	Play/Pause	PLAY MODE	Play
STOP	Stop		Stop
RETURN	Return	RETURN BACK	Back

Original		Replacement	
MUTE	Mute	MUTE	Mute
VOL +	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
CH+	Up		Up
CH+	CH+	+ CH	Ch +
CH–	CH-	CH –	Ch -
CH–	Down		Down
	Right		Right
	Left		Left
SYS MENU	Sys Menu	TOP MENU MENU	Menu
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
OK	OK	OK	Ok
PICTURE	Picture	PICTURE FORMAT	Format
SOUND	Sound	SOUND DUAL	Dual
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
NICAM/A2	Nicam/A2	APP MEDIA	Media
PROG – LAN	Lan/Prog-	SHIFT + CH –	Shift + Ch -

Original	Replacement	Original	Replacement
PROG+ ZOOM Zoom/ Prog+	SHIFT + CH + Shift + Ch +	SUBTITLE A-B Blue/ A-B/ Subtitl	D Blue
SUB Sub	AD SUBT Subt		
GOTO Goto	SETTINGS OPT Options		
TV/TXT DVB-MENU SET SET/ Tv/ TXT/ DVB-	REPEAT TEXT Text		
REVEAL EXIT ANG ANG/ Reveal / Exit	CLEAR EXIT Exit		
CANCEL TV FORMAT MENU Menu/ Cancel / Tv Format	E-MANUAL D.MENU D. Menu		
INFO TITLE Title/ info	DISPLAY INFO Info		
HOLD LANGUAGE << << / Hold/ Languag	<< <<		
SIZE TEXT >> >> / Size/ Text	>> >>		
SUBPAGE FAV I << I << / Subpage	I << I <<		
SUBPAGE FAV FAV	FAV PRE-CH Pre Ch		
INDEX EPG >>I >>I / Index	>>I >>I		
INDEX EPG EPG	-/-- GUIDE Guide		
TV/RADIO PRO Red/ Pro	A Red		
TV/RADIO PRO Tv/ Radio	SEARCH TV/R TV/R		
AUDIO SLOW Green/ Slow/ Audio	B Green		
FREEZE REP Yellow/ Rep/ Freeze	C Yellow		