Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1./@	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
LANG.	Lang	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
TXT	TXT	GOTO TEXT	Text / Goto
+ V	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+

Original		Replacement	
V –	Vol -	VOL –	Vol -
	Home	HOME MENU	Menu / Home
P	P-	CH PAGE –	CH- / Page-
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
YouTube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
i	i	ANGLE INFO	Info / Angle
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Play	FPay	SHIFT + APP REPEAT	Shift + Green / APP /
	☼1	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Green	APP / REPEAT — Green / APP / Repeat		
Yellow	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM — Blue / Prime Video / Random		
<<	TUNE- — << / Tune-		
Pause	STEP-FREEZE — Pause / Step / Freeze		
>>	TUNE+ — >> / Tune+		
Rec	REC MODE — Rec / Rec Mode		
Play	SLOW — Play / Slow		
Stop	HOLD — Stop / Hold		