Original	Replacement	Original	Replacement
Power	Power	S	AV / Input / RDS
Mute	Mute / Dimmer	Back	Back / Return
<<	<< / Tune-	Vol-	Vol-
Zoom	Zoom / Size	Vol+	Vol+
[I]	Display / Media		
[--]	Smart / List		
>>	>> / Tune+		
I<<	I<< / Preset-		
Play/Pause 2	Pause / Step / Freeze		
Play/Pause 1	Play / Slow		
>>I	>>I / Preset+		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
M	Menu / Home		

https://mandos-a-distancia.es/en/WiMiUS/1067574-96363-replacement-remote-control-for-WiMiUS-P20.html