Original		Replacement	
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
EXIT	Exit	CLEAR EXIT	Exit
TEXT	Text	REPEAT TEXT	Text
AUDIO I/II	Audio I/II	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
V+	V+	+ VOL	Vol +
V-	V-	VOL −	Vol -
SOURCE	Red / Source	TIMER AV	AV
SOURCE	Red / Source	SHIFT + A	Shift + Red
TV MENU	Green / TV	TOP MENU MENU	Menu
TV MENU	Green / TV	SHIFT + B	Shift + Green
PMODE	Yellow / PMode	PICTURE FORMAT	Format
PMODE	Yellow / PMode	SHIFT + C	Shift + Yellow

Original		Replacement	
SMODE	Blue / SMode	SHIFT + SOUND DUAL	Shift + Dual
SMODE	Blue / SMode	SHIFT + D	Shift + Blue
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original	Replacement
-/--	SHIFT + GUIDE (Shift + Guide)
Recall	RETURN BACK (Back)
Red	A (Red)
Green	B (Green)
Yellow	C (Yellow)
Blue / Repeat	D (Blue)
Blue / Repeat	SHIFT + REPEAT TEXT (Shift + Text)
Subtitle	AD SUBT (Subt)
Pause/Play / Hold	PLAY MODE ▶ (Play)
Pause/Play / Hold	II (Pause)
Size	ECO 3D (3D)
Mix	E-MANUAL D.MENU (D. Menu)
Reveal	SHIFT + DISPLAY INFO (Shift + Info)
TXT Index	ZOOM ⏏ (Eject)
I<< / Subpage	I<<
>>I / Lang	>>I
Stop / FAV -	■ (Stop)

Original	Replacement
Stop / FAV -	SHIFT + ◀ (Shift + Left)
<< / FAV	<<
<< / FAV	FAV PRE-CH (Pre Ch)
>> / FAV+	>>
>> / FAV+	SHIFT + ▶ (Shift + Right)
EPG	-/-- GUIDE (Guide)
USB/SD	APP MEDIA (Media)
Recorder	REC MODE ● (Rec)
CH.List	DISC NAV LIST (List)
TV / Radio	SEARCH TV/R (TV/R)