Mandis shop

Saba TC352

Original		Sustituto	
ON/OFF	On/Off		Power
	Channel-	CH −	CH -
	Channel+	+ CH	CH +
REW	<< Rew		Rewind
REW	<<Shuttle/Search		First
FF	FF >>		Fast Forward
FF	Shuttle/Search		Last
	Play		Play
	Stop		Stop
REC	Rec		Rec
PAUSE	Pause		Pause

Original	Sustituto

https://mandos-a-distancia.es/es/1009816-83688-mando-de-sustitucion-para-Saba-TC352.html