Mandis shop

RC4870

Original	Sustituto
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
Lang	Audio / Lang I/II
Source (Games)	Eject / Surround
Movie-Music-Phot	Picture / Format
[≡]. .	Zoom / Size
*/O	Sleep / Timer
TV	TV/Radio /
Q. Menu	D. Menu / Top
[-O-]	Setup / OPT /
[≡]/Text	Text / Goto

Original	Sustituto
Menu	Menu / Home
Up	Up
i	Info / Angle
Left	Left
OK	OK
Right	Right
Exit	Exit / Cancel / Clear
Down	Down
Back	Back / Return
Vol +	Vol +
World (Violet)	Smart / List
PR+	CH+ / Page+
Vol -	Vol -
*/Q	Display / Media
PR-	CH- / Page-
1	1
2	2

Original	Sustituto	Original	Sustituto
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
Guide	Guide / EPG / -/--		
0	0		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Recall	Shift + Back / Return		