Original		Sustituto	
	Power		Power
	Mute	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Vol +	+ VOL	Vol +
	Left		Left
	Vol -	VOL −	Vol -
TV/AV	Tv/AV	TIMER AV	AV
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
F.P.	[≡♦] / F. P.	TOP MENU MENU	Menu
INDEX	[≡i] / Index	DISPLAY INFO	Info
HOLD	[≡+] / Hold	PICTURE FORMAT	Format
TV/TEXT	[≡] / Tv/Text	REPEAT TEXT	Text

Original		Sustituto	
SET UP	Set Up	APP MEDIA	Media
SOUND	[♪] / Sound	SOUND DUAL	Dual
PICTURE	[ ] / Picture	AD SUBT	Subt
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0/VCR	0	0
-/--	-/--	-/-- GUIDE	Guide
SURROUND	OO/Surround	SETTINGS OPT	Options
ASPECT	[+] / Aspect	ECO 3D	3D
	Play VCR	PLAY MODE	Play

Original	Sustituto
Stop VCR	Stop
>> VCR	>>
<< VCR	<<
Power VCR	SHIFT + Power (Shift + Power)
Rec VCR	REC MODE (Rec)
N VCR/DVD	SHIFT + SETTINGS OPT (Shift + Options)
Pause VCR	Pause
STR VCR/DVD	CLEAR EXIT (Exit)
Programe- VCR	CH − (Ch -)
Programe+ VCR	+ CH (Ch +)
Power DVD	SHIFT + HOME SMART (Shift + Smart)
Play DVD	OK (Ok)
Stop DVD	SHIFT + ▼ (Shift + Down)
I/II/O)/▼	HOME SMART (Smart)
[+]	FAV PRE-CH (Pre Ch)
Pause DVD	SEARCH TV/R (TV/R)
>>I DVD	>>I

Original	Sustituto
I << DVD	I <<
<< DVD	SHIFT + ◀ (Shift + Left)
>> DVD	SHIFT + ▶ (Shift + Right)