Original		Sustituto	
	Power		Power
	HDMI / Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
ZOOM	Red/ Zoom/ ↑↓	A	Red
REPEAT	Green/ Repeat / ↓	B	Green
ROOT	Yellow/ Root	C	Yellow
TITLE	Blue/ Title	D	Blue
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Sustituto	
	Internet / PIP	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
INFO	Info	DISPLAY INFO	Info
SOURCE	Source	TIMER AV	AV
OK	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down

Original		Sustituto		Original	Sustituto
	Right		Right		
	Left		Left		
P+	P+	+ CH	Ch +		
P-	P-	CH −	Ch -		
V+	Vol +	+ VOL	Vol +		
V-	Vol -	VOL −	Vol -		
MENU	Menu	TOP MENU MENU	Menu		
	Mute	MUTE	Mute		
RETURN	Return	RETURN BACK	Back		
SWAP	Swap	FAV PRE-CH	Pre Ch		
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch		
EPG	EPG	-/-- GUIDE	Guide		
SLEEP	Sleep	PROG SLEEP	Sleep		
SEARCH MODE	Search Mode	SHIFT + TIMER AV	Shift + AV		
	Ball / Angle	SETTINGS OPT	Options		
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info		
PRESETS	Presets	SEARCH TV/R	TV/R		