| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| DTV/VCR | RDS AV INPUT — AV / Input / RDS | Right | Right |
| STANDBY — Standby | Power | Vol + | VOL + — Vol + |
| REC — PVR Rec | REC MODE — Rec / Rec Mode | FAVOURITE — Favourite | PC FAV MARKER — Fav / Marker / PC |
| LIST — PVR List | LIST SMART — Smart / List | CH- | CH PAGE − — CH- / Page- |
| MUTE — Mute | DIMMER MUTE — Mute / Dimmer | Down | Down |
| EPG | -/-- GUIDE EPG — Guide / EPG / -/-- | TV/RADIO — Tv/Radio | PROGRAM TV/RADIO — TV/Radio / |
| INFO — Info | ANGLE INFO — Info / Angle | 1 — 1 | TV 1 — 1 |
| TTX | GOTO TEXT — Text / Goto | 2 — 2 | DVD 2 — 2 |
| AUDIO — Audio | LANG I/II AUDIO — Audio / Lang I/II | 3 — 3 | CD-STB 3 — 3 |
| SUBTITLE — Subtitle | EQ SUBTITLE — Subtitle / EQ | RECALL — Recall | RETURN BACK — Back / Return |
| MENU — Menu | HOME MENU — Menu / Home | 4 — 4 | VIDEO 4 — 4 |
| Up | Up | 5 — 5 | TAPE 5 — 5 |
| CH+ | CH PAGE + — CH+ / Page+ | 6 — 6 | TUNER 6 — 6 |
| EXIT — EXit | CLEAR EXIT CANCEL — Exit / Cancel / Clear | GOTO — Goto | SHIFT + GOTO TEXT — Shift + Text / |
| Left | Left | 7 — 7 | AUX-HDD 7 — 7 |
| Vol - | VOL − — Vol - | 8 — 8 | USB 8 — 8 |
| OK — OK | OK — OK | 9 — 9 | BLUETOOTH 9 — 9 |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| REV | <<| Rev | TUNE- | << / Tune- | | |
| FWD | >>| Fwd | TUNE+ | >> / Tune+ | | |
| PREV | I <<| Prev | PRESET- | I << / Preset- | | |
| NEXT | >>I / Next | PRESET+ | >>I / Preset+ | | |
| PLAY | Play | SLOW | Play / Slow | | |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze | | |
| STOP | Stop | HOLD | Stop / Hold | | |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |