Original		Sustituto	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CD/DVD	CD/DVD	DVD 2	2
CD/DVD	CD/DVD	CD-STB 3	3
PHONO	Phono	TV 1	1
TUNER	Tuner	TUNER 6	6
STANDBY	Standby	SHIFT +	Shift + Power
MD	MD	VIDEO 4	4
TAPE	Tape	TAPE 5	5
AUX	AUX	AUX-HDD 7	7
SPEAKERS A	Speakers A	NETFLIX SEARCH	Red / Netflix / Search
B	Speakers B	APP REPEAT	Green / APP / Repeat
PRESET	Preset Up	+ CH PAGE	CH+ / Page+
VOLUME +	Vol +	+ VOL	Vol +
PRESET	Preset Down	CH PAGE –	CH- / Page-
VOLUME –	Vol -	VOL –	Vol -
A/B/C/D/E	A/B/C/D/E		Up

Original		Sustituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
<<	<< Device CD	TUNE- <<	<< / Tune-
<<	<< Device	SHIFT + TUNE- <<	Shift + << /
A/B ▮▮	Pause/A/B Device	STEP-FREEZE ▮▮	Pause / Step / Freeze
A/B ▮▮	Pause/A/B Device Tape	SHIFT + STEP-FREEZE ▮▮	Shift + Pause / Step /
>>	>> Device CD	TUNE+ >>	>> / Tune+
>>	>> Device	SHIFT + TUNE+ >>	Shift + >> /
DISPLAY	Display Device CD	MEDIA DISPLAY	Display / Media
DIR A FREQ/TEXT	I<< / Freq/Text/Di	◀	Left
DIR A FREQ/TEXT	I<< / Freq/Text/Di A Device CD	PRESET- I<<	I<< / Preset-
DIR A FREQ/TEXT	I<< / Freq/Text/Di A Device Tape	SHIFT + PRESET- I<<	Shift + I<< / Preset-
MODE – PTY	Stop/Mode-PTY	▼	Down
MODE – PTY	Stop/Mode-PTY Device CD	HOLD ■	Stop / Hold
MODE – PTY	Stop/Mode-PTY Device Tape	SHIFT + HOLD ■	Shift + Stop /
DIR B >>I SEEK – START	>>I / Seek-Start/Dir B	▶	Right
DIR B >>I SEEK – START	>>I / Seek-Start/Dir B Device CD	PRESET+ >>I	>>I / Preset+
DIR B >>I SEEK – START	>>I / Seek-Start/Dir B Device Tape	SHIFT + PRESET+ >>I	Shift + >>I / Preset+

Original	Sustituto	Original	Sustituto
DISC Disc/Eon/Rec	OK OK		
DISC Disc/Eon/Rec Device CD	SURROUND Eject / Surround		
DISC Disc/Eon/Rec Device Tape	SHIFT + REC MODE Shift + Rec / Rec Mode		
Play Device CD	SLOW Play / Slow		
Play Device Tape	SHIFT + SLOW Shift + Play /		