Original	Sustituto	Original	Sustituto
Standby	Power	Timer	-/-- / EPG
Teletex	TEXT	Menu	MENU
Red	Red (A)	Mute	MUTE
Green/[ ] Smart	Green (B)	P<P	P/C / FAV
Yellow/♪ Smart	Yellow (C)	OK	OK
Blue	Blue (D)	Up	UP
1	1	Down	DOWN
2	2	Right	RIGHT
3	3	Left	LEFT
4	4	P+	CH +
5	5	P-	CH -
6	6	Vol +	VOL +
7	7	Vol -	VOL -
8	8	Play	Play
9	9	Stop	Stop
0	0	Record/OTR	Rec
Clear	EXIT	<<	Rewind

Original	Sustituto	Original	Sustituto
>>	Fast Forward		
>I / Index	Last		
>I ◁/ Still	Pause		