Original		Sustituto	
	Power		Power
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
LIST	List	SHIFT + LIST SMART	Shift + Smart / List
0 SPACE	0	HDMI - SAT 0	0
PRE-CH	Pre-CH	SHIFT + RETURN BACK	Shift + Back / Return
+ V	Vol+	+ VOL	Vol+
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+
V −	Vol-	VOL −	Vol-

Original		Sustituto	
INFO	Info	ANGLE INFO	Info / Angle
P	P-	CH PAGE −	CH- / Page-
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
SMART TV	Smart TV	LIST SMART	Smart / List
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Back	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
3D	3D	FORMAT PICTURE	Picture / Format
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Original	Sustituto	Original	Sustituto
Sleep	Sleep / Timer		
Text	Text / Goto		
O)/Lang	Audio / Lang I/II		
Subtitle	Subtitle / EQ		
<<	<< / Tune-		
Pause	Pause / Step / Freeze		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Play	Play / Slow		
Stop	Stop / Hold		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		