Original	Sustituto	Original	Sustituto
Power	Power	Menu	Menu
Mute	Mute	EPG	Guide
1	1	Exit	Exit
2	2	OK	Ok
3	3	Up	Up
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
FAV	Pre Ch	Red	Red
Recall	Back	Green	Green
Game	Media	Yellow	Yellow
Auto	Smart	Blue	Blue
Info	Info	Zoom	Eject

Original		Sustituto		Original	Sustituto
LAN/AUDIO	Lan/ Audi o	SOUND DUAL	Dual		
PLAY/PAUSE	Pl ay	PLAY MODE	Pl ay		
PLAY/PAUSE	Pause	II	Pause		
TV/RADIO	<<	<<	<<		
SUBTITLE	>>	>>	>>		
TEXT	Text	REPEAT TEXT	Text		
TV/RADIO	Tv/ Radi o	SEARCH TV/R	TV/ R		
SUBTITLE	Subt i t l e	AD SUBT	Subt		