Original		Sustituto	
	Power BD		Power
	Eject	ZOOM	Eject
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
TITLE MENU POPUP	Popup/Title Menu	TOP MENU MENU	Menu
	I<<		I<<
	>>I		>>I

Original		Sustituto	
	<<		<<
	>>		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
TV VOL +	Vol + Tv	VOL +	Vol +
TV VOL −	Vol - Tv	VOL −	Vol -
TV MUTE	Mute Tv	MUTE	Mute
PROG	Prog+	CH +	Ch +
PROG	Prog-	CH −	Ch -
CH LIST	CH List	DISC NAV LIST	List
HOME	Home	SHIFT + HOME SMART	Shift + Smart
GUIDE	Guide	GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit

Original	Sustituto	Original	Sustituto
Up	Up		
Down	Down		
Right	Right		
Left	Left		
Enter	OK		
Red/A	Red		
Green/B	Green		
Yellow/C/PIP CH-	Yellow		
Blue/D/PIP CH+	Blue		
Smart Hub	Smart		
Search	Shift + TV/R		
PIP	Format		
2D-3D	3D		
WWW	Media		
TV Social	TV/R		
Rec	Rec		
Pause/Rec	Shift + Pause		

Original	Sustituto
Power Tv	Power
TTX/MIX	Text
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
I <<	I <<
>>I	>>I
<<	<<
>>	>>
Stop	Stop

Original	Sustituto
Play	Play
Pause	Pause
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Prog+	Ch +
Prog-	Ch -
Source	AV
CH List	List
Home	Shift + Smart
Guide	Guide
Tools	Options
Info	Info
Return	Back
Exit	Exit
Up	Up
Down	Down

Original		Sustituto	
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red/ A	A	Red
B	Green/ B	B	Green
PIP CH − C	Yellow/ C	C	Yellow
PIP CH + D	Blue/ D	D	Blue
SMART HUB	Smart Hub	HOME SMART	Smart
SEARCH	Search	SEARCH TV/R	TV/ R
2D→3D	2D- 3D	ECO 3D	3D
REC	Rec	REC MODE	Rec

Original	Sustituto