Original		Sustituto	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Sustituto	
CH LIST	CH-List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
MEDIA.P	Media. P	APP MEDIA	Media
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN BACK	Return/Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
A	Red/A	A	Red
B	Green/B	B	Green

Original	Sustituto	Original	Sustituto
C Yellow/ C	C Yellow		
D Blue/ D	D Blue		
P.MODE P. Mode	SHIFT + PICTURE FORMAT Shift + Format		
S.MODE S. Mode	SHIFT + SOUND DUAL Shift + Dual		
D	ECO 3D 3D		
I-II DUAL Dual / I - I I	SOUND DUAL Dual		
P.SIZE P. Size	PICTURE FORMAT Format		
SUBT. Subt.	AD SUBT Subt		
<<	<<		
Pause	Pause		
>>	>>		
Rec	REC MODE Rec		
Play	PLAY MODE Play		
Stop	Stop		