Mandis shop

Panasonic N2QAYB000728

Original		Sustituto	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Cancel		-/-- / EPG
	Audio		Audio
	Vol +		VOL +
	Vol -		VOL -
	Mute		MUTE
	Disc/SD		SRC

Original		Sustituto	
	iPod/Radio/Ext-I		TV/R
	Netflix		Shift + MEDIA
	<< Search/Slow		Rewind
	Play		Play
	Search/Slow >>		Fast Forward
	I<< Skip/↓		First
	Pause		Pause
	Skip >>I/↑		Last
	Stop		Stop
	Status		INFO
	X/Exit		EXIT
	Option		OPT+
	Return		BACK
	Internet		MEDIA
	Home		VOD
	Pop-Up Menu/Top Menu		MENU
	Up		UP

Original		Sustituto	
	Down		DOWN
	Right / II >		RIGHT
	< II / Left		LEFT
OK	OK	OK	OK
	Red	A	Red (A)
	Green	B	Green (B)
	Yellow	C	Yellow (C)
	Blue	D	Blue (D)
SOUND	Sound		Subt.
SURROUND -SLEEP	Surround/Sleep	WIDE	WIDE
CH SELECT	CH Select	FAV 2. P/C	P/C / FAV
	Skipe	V-FOR	V-FOR
TV	Power Tv	SHIFT +	Shift + Power
INPUT AV	Av/Input Tv	SHIFT + SRC	Shift + SRC
+ VOL	Vol + Tv	+ CH	CH +
-	Vol - Tv	CH -	CH -

Original	Sustituto