Original		Sustituto	
POWER	Power		Power
INPUT	Input	TIMER AV	AV
MULTIMEDIA	Multimedia	APP MEDIA	Media
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	Rec	REC MODE	Rec
	<<		<<
MARK	>>		>>
	I <<		I <<
LIVE TV	>>I		>>I
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
XSTUDIO	XStudioPro	HOME SMART	Smart
	Up		Up
	Down		Down
	Left		Left

Original		Sustituto	
	Right		Right
OK	Ok	OK	Ok
PIP PR-	Red	A	Red
PIP PR+	Green	B	Green
SWAP	Yellow	C	Yellow
PIP INPUT	Blue	D	Blue
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
TEXT	Text	REPEAT TEXT	Text
PR	PR+	+ CH	Ch +
PR	PR-	CH –	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Sustituto	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List
Q.VIEW	Q. View	SETTINGS OPT	Options
SIZE	Size	PICTURE FORMAT	Format
POSITION	Position	AD SUBT	Subt
INDEX	Index	DISPLAY INFO	Info
TIME	Time	SHIFT +	TIMER AV Shift + AV
SLEEP	Sleep	PROG SLEEP	Sleep
REVEAL	Reveal	E-MANUAL D.MENU	D. Menu
HOLD	Hold	SEARCH TV/R	TV/R
FAV	Fav	FAV PRE-CH	Pre Ch
PIP	PIP	ECO 3D	3D
ARC	ARC	-/-- GUIDE	Guide

Original		Sustituto	
I/II	I/II	SOUND DUAL	Dual

Original		Sustituto	
POWER	Power		Power
INPUT	I nput	TIMER AV	AV
	St op		St op
	Pl ay	PLAY MODE	Pl ay
	Pause		Pause
	Rec	REC MODE	Rec
	<<		<<
MARK	>>		>>
PR	PR+	CH +	Ch +
PR	PR-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Sustituto	
8	8	8	8
9	9	9	9
0	0	0	0