Original		Sustituto	
POWER	Power	POWER	Power
OPEN /CLOSE	Open/Close	ZOOM	Eject
DVD TV SYS	DVD	A	Red
TUNER	Tuner	B	Green
VIDEO	Video	C	Yellow
TV/AUX	TV/AUX	D	Blue
SLEEP	Sleep	PROG SLEEP	Sleep
	I<<		I<<
	<<		<<
	>>		>>
	>>I		>>I
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
	SP.Setup	APP MEDIA	Media
	CH-Level	GUIDE	Guide
	SR.Mode	DISC NAV LIST	List
	Title	DISPLAY INFO	Info

Original		Sustituto	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
VOL	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
SET UP	Setup	SETTINGS OPT	Options
PAUSE/STEP	Pause/Step	II	Pause
MENU/RETURN	Menu/Return	TOP MENU MENU	Menu
GO TO AUTO MEMORY	Goto Auto	RETURN BACK	Back
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original	Sustituto
6	6
7	7
8	8
9	9
0	0
DISP/FM MODE DISP/FM mode	SEARCH TV/R TV/R
DELAY TIME Delay Time	CLEAR EXIT Exit
TEST TONE Test Tone	PICTURE FORMAT Format
SUBTITLE Subtitle	AD SUBT Subt
SLOW Slow	TIMER AV AV
AUDIO Audio	SOUND DUAL Dual
A-B A-B	HOME SMART Smart
ZOOM Zoom	SHIFT + ZOOM Shift + Eject
ANGLE Angle	ECO 3D 3D
RANDOM Random	E-MANUAL D.MENU D. Menu
REPEAT Repeat	REPEAT TEXT Text
DIGEST RDS MODE Digest RDS Mode	SHIFT + AD SUBT Shift + Subt

Original	Sustituto
MPX PTY SEARCH MPX PTY Search	SHIFT + TIMER AV Shift + AV
PBC PBC	SHIFT + SEARCH TV/R Shift + TV/R