Mandis shop

FRANSAT 060660PVR

Original		Sustituto	
3D	3D	FORMAT PICTURE	Picture / Format
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
PROG+	Prog+	+ CH PAGE	CH+ / Page+
0	0	HDMI - SAT 0	0
VOL+	Vol+	+ VOL	Vol+
PROG-	Prog-	CH PAGE −	CH- / Page-
VOL-	Vol-	VOL −	Vol-

Original		Sustituto	
CH+	Up/CH+		Up
VOL -	Left/Vol-		Left
OK	OK	OK	OK
VOL +	Right/Vol+		Right
CH-	Down/CH-		Down
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
LIST	List	LIST SMART	Smart / List
TXT	TXT	GOTO TEXT	Text / Goto
S-T	S-T	TITLE SOUND	Sound / Title
TVR	Tv/R	PROGRAM TV/ RADIO	TV/Radio /
TIMER	Timer	TIMER SLEEP	Sleep / Timer
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze

Original		Sustituto	
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	←	RETURN BACK	Back / Return
	<<	TUNE-	<< / Tune-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	>>	TUNE+	>> / Tune+
	Green	APP REPEAT	Green / APP / Repeat
	I<<	PRESET-	I<< / Preset-
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	>>I	PRESET+	>>I / Preset+
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Sustituto