Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
	Internet	LIST SMART	Smart / List
TV/Radio	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	Music/Movie/Pict	MEDIA DISPLAY	Display / Media
LIB	LIB	TOP MENU D.MENU	D.Menu / Top Menu

Original		Sustituto	
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
P↔P	P↔P	PRESET-	I<< / Preset-
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
CH ▲	CH+	CH + PAGE	CH+ / Page+
CH ▼	CH-	CH PAGE −	CH- / Page-
INFO	Info	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
BACK	Back	RETURN BACK	Back / Return
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	OK
●	Rec	REC MODE ●	Rec / Rec Mode
▶	Play	SLOW ▶	Play / Slow

Original	Sustituto	Original	Sustituto
Stop	HOLD Stop / Hold		
<<	TUNE- << / Tune-		
Pause	STEP-FREEZE Pause / Step / Freeze		
>>	TUNE+ >> / Tune+		
TEXT Text	GOTO TEXT Text / Goto		
SUBT. SUBT.	EQ SUBTITLE Subtitle / EQ		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
OPT OPT	OPT-TOOLS SETUP Setup / OPT /		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		