Original		Sustituto	
	Power		Power
	HDMI Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	I <<		I <<
	<<		<<
	>>		>>
	>>I		>>I
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
	PIP / World	ECO 3D	3D
ZOOM	Red / Zoom	A	Red
REPEAT	Green / Repeat	B	Green
ROOT	Yellow / Root	C	Yellow

Original		Sustituto	
TITLE	Blue / Title	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
SWAP	Swap	FAV PRE-CH	Pre Ch
	Up		Up
	Right		Right
	Down		Down
	Left		Left

Original		Sustituto	
OK	OK	OK	Ok
P/CH +	P/CH +	CH +	Ch +
P/CH -	P/CH -	CH -	Ch -
Mute	Mute	MUTE	Mute
Vol +	Vol +	VOL +	Vol +
Vol -	Vol -	VOL -	Vol -
MENU	Menu	TOP MENU MENU	Menu
SOURCE	Source	TIMER AV	AV
RETURN	Return	RETURN BACK	Back
EPG	EPG	-/-- GUIDE	Guide
INFO	Info	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
	Angle / Media	APP MEDIA	Media
SEARCH MODE	Search Mode	SEARCH TV/R	TV/R
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
PRESETS	Presets	DISC NAV LIST	List

Original	Sustituto