Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause [/≡]	STEP-FREEZE	Pause / Step / Freeze
	Stop/[≡+]	HOLD	Stop / Hold
	Rec/[≡♦]	REC MODE	Rec / Rec Mode
	<</[≡o]	TUNE-	<< / Tune-
	I<</[≡i]	PRESET-	I<< / Preset-
	>>I/[≡?]	PRESET+	>>I / Preset+
	>>/[≡x]	TUNE+	>> / Tune+
INFO	Info	ANGLE INFO	Info / Angle
AUDIO	O)I/II/Audio	LANG I/II AUDIO	Audio / Lang I/II
	[≡]	GOTO TEXT	Text / Goto
	↩/<x]	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Sustituto	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
☼	☼	OPT-TOOLS SETUP	Setup / OPT /
[→]	[→]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-BAT 0	0
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
You Tube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
+	Vol +	+ VOL	Vol +

Original		Sustituto	
SOURCE	Home/ Sour ce	HOME MENU	Menu / Home
P	P+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
P	P-	CH PAGE	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Gr een	APP REPEAT	Green / APP / Repeat
	Yel l ow	YouTube REPEAT A-B	Yel l ow / YouTube / Repeat
	Bl ue	Prime Video RANDOM	Bl ue / Pr ime Vi deo / Random
EPG	EPG	-/-- GUIDE EPG	Gui de / EPG / -/--
LIST	Li st	LIST SMART	Smart / List
QMENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top

Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause/[/≡]	STEP-FREEZE	Pause / Step / Freeze
	Stop/[≡+]	HOLD	Stop / Hold
	Rec/[≡♦]	REC MODE	Rec / Rec Mode
	<</[≡o]	TUNE-	<< / Tune-
	I<</[≡i]	PRESET-	I<< / Preset-
	>>I/[≡?]	PRESET+	>>I / Preset+
	>>/[≡x]	TUNE+	>> / Tune+
INFO	Info	ANGLE INFO	Info / Angle
AUDIO	OI/II/Audio	LANG I/II AUDIO	Audio / Lang I/II
	[≡]	GOTO TEXT	Text / Goto
	↩/<x]	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Sustituto	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
☼	☼	OPT-TOOLS SETUP	Setup / OPT /
0	0	HDMI-SAT 0	0
[→]	[→]	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
You Tube	You Tube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
+ VOL	Vol +	+ VOL	Vol +

Original		Sustituto		Original	Sustituto
SOURCE	Home / Source	HOME MENU	Menu / Home		
P	P+	CH PAGE +	CH+ / Page+		
	Vol -	VOL −	Vol -		
P	P-	CH PAGE −	CH- / Page-		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
LIST	List	LIST SMART	Smart / List		
QMENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top		