| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause [ / ≡] | STEP-FREEZE | Pause / Step / Freeze |
| | Stop/ [ ≡+] | HOLD | Stop / Hold |
| | Rec/ [ ≡◆] | REC MODE | Rec / Rec Mode |
| | <<I [ ≡o] | TUNE- | << / Tune- |
| | I <<I [ ≡i ] | PRESET- | I << / Preset- |
| | >>I / [ ≡?] | PRESET+ | >>I / Preset+ |
| | >>I [ ≡x] | TUNE+ | >> / Tune+ |
| INFO | Info | ANGLE INFO | Info / Angle |
| AUDIO | O)I / II / Audio | LANG I/II AUDIO | Audio / Lang I/II |
| | [ ≡] | GOTO TEXT | Text / Goto |
| | ↵/ <x] | RETURN BACK | Back / Return |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |

| Original | | Sustituto | |
|---|---|---|---|
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| ☼ | ☼ | OPT-TOOLS SETUP | Setup / OPT / |
| | [ →] | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 0 | 0 | HDMI-SAT 0 | 0 |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| NETFLIX | Netflix | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| YouTube | YouTube | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| + | Vol + | + VOL | Vol + |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Home/ Sour ce | Menu / Home | | |
| P+ | CH+ / Page+ | | |
| Vol - | Vol - | | |
| P- | CH- / Page- | | |
| Red | Red / Netflix / Search | | |
| Gr een | Green / APP / Repeat | | |
| Yel l ow | Yel l ow / YouTube / Repeat | | |
| Bl ue | Bl ue / Pri me Vi deo / Random | | |
| EPG | Gui de / EPG / -/-- | | |
| Li st | Smart / Li st | | |
| Q. Menu | D. Menu / Top | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause/[ /≡] | STEP-FREEZE | Pause / Step / Freeze |
| | Stop/[ ≡+] | HOLD | Stop / Hold |
| | Rec/[ ≡♦] | REC MODE | Rec / Rec Mode |
| | <<I [ ≡o] | TUNE- | << / Tune- |
| | I <<I [ ≡i ] | PRESET- | I << / Preset- |
| | >>I / [ ≡?] | PRESET+ | >>I / Preset+ |
| | >>I [ ≡x] | TUNE+ | >> / Tune+ |
| INFO | Info | ANGLE INFO | Info / Angle |
| AUDIO | OI / II / Audio | LANG I/II AUDIO | Audio / Lang I/II |
| | [ ≡] | GOTO TEXT | Text / Goto |
| | ↵/ <x] | RETURN BACK | Back / Return |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |

| Original | | Sustituto | |
|---|---|---|---|
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| ☼ | ☼ | OPT-TOOLS SETUP | Setup / OPT / |
| 0 | 0 | HDMI-SAT 0 | 0 |
| | [→] | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| NETFLIX | Netflix | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| You Tube | You Tube | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| + | Vol + | + VOL | Vol + |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Home / Source | Menu / Home | | |
| P+ | CH+ / Page+ | | |
| Vol - | Vol - | | |
| P- | CH- / Page- | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| EPG | Guide / EPG / -/-- | | |
| List | Smart / List | | |
| Q. Menu | D. Menu / Top | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |