Original		Sustituto	
	Power		Power
	V-Mode		D.Menu / Top
	Mute		Mute / Dimmer
	SAT		Shift + 0
	SAT		Display / Media
	TV / AV		AV / Input / RDS
	Zoom		Zoom / Size
	Sleep		Sleep / Timer
	1		1
	2		2
	3		3
	FAV		Fav / Marker / PC
	4		4
	5		5
	6		6
	Pause		Pause / Step / Freeze
	7		7

Original		Sustituto	
	8		8
	9		9
	Page +		Shift + CH+ /
	TV / Radio		TV/Radio /
	0		0
	<-- PR		Back / Return
	Page -		Shift + CH- /
	Up / PR +		CH+ / Page+
	Up / PR +		Up
	Left / Vol -		Left
	Left / Vol -		Vol-
	OK / List		Smart / List
	OK / List		OK
	Right / Vol +		Right
	Right / Vol +		Vol+
	Down / PR -		CH- / Page-
	Down / PR -		Down

Original		Sustituto	
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
FIND	Red / Find	NETFLIX SEARCH	Red / Netflix / Search
V-FORMAT	Green / V-Format	FORMAT PICTURE	Picture / Format
V-FORMAT	Green / V-Format	APP REPEAT	Green / APP / Repeat
TXT	Yellow / TXT	GOTO TEXT	Text / Goto
TXT	Yellow / TXT	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / Audio	LANG I/II AUDIO	Audio / Lang I/II
	Blue / Audio	Prime Video RANDOM	Blue / Prime Video / Random
RECORD	Record	REC MODE	Rec / Rec Mode
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
FAST	<< Fast	TUNE-	<< / Tune-
FAST	>> Fast	TUNE+	>> / Tune+

Original		Sustituto	
SLOW	< Slow	PRESET-	I<< / Preset-
SLOW	> Slow	PRESET+	>>I / Preset+