Mandis shop

Pioneer AXD 7187

Original	Sustituto
Standby AMP	Power
Standby CD	1
Standby Tuner	2
Standby Tape	3
Tape Select	Media
< Tape Deck II	Shift + Left
< Tape Deck I	Left
Stop Tape Deck I	Shift + Ok
Stop Tape Deck I	Ok
> Tape Deck I	Right
> Tape Deck II	Shift + Right
<< Tape Deck I	<<
<< Tape Deck	Shift + <<
>> Tape Deck	Shift + >>
>> Tape Deck I	>>
I << CD	I <<
>>I CD	>>I

Original	Sustituto
Stop CD	Stop
Play CD	Play
Disc Select	Smart
- Station Tune	Ch -
Station + Tune	Ch +
CD	4
Tuner	5
Phono	6
Tape 1	7
Tape 2	8
Line	9
Vol +	Vol +
Vol -	Vol -