Original		Sustituto	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
Subtitle	Subtitle	EQ SUBTITLE	Subtitle / EQ
0	0	HDMI - SAT 0	0
Teletext	Teletext	GOTO TEXT	Text / Goto
Info	Info	ANGLE INFO	Info / Angle
	Up		Up
Recall	Recall	RETURN BACK	Back / Return
	Left		Left

Original		Sustituto	
OK	OK	OK	OK
	Right		Right
Menu	Menu	HOME MENU	Menu / Home
	Down		Down
Exit	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
Play List	Play List	SHIFT + SLOW	Shift + Play /
	Vol +	VOL +	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
CH	CH +	CH PAGE +	CH+ / Page+
VOL	Vol -	VOL −	Vol -
CH	CH -	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Sustituto	Original	Sustituto
<<	<< / Tune-		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
>>	>> / Tune+		
I<	I<< / Preset-		
Stop	Stop / Hold		
Rec	Rec / Rec Mode		
>I	>>I / Preset+		
Page Up	Shift + CH+ /		
Page Down	Shift + CH- /		
TV/Radio / Source	TV/Radio /		
TV/Radio / Source	AV / Input / RDS		
Resolution	D.Menu / Top		
✓	Display / Media		
PIP	Zoom / Size		
PIP Swap	Picture / Format		
PIP List	Smart / List		