Original	Sustituto
Standby	Power
Mute	Mute
P/N	Smart
Open/Close	Eject
<<	<<
>>	>>
Play/Pause	Play
Stop	Stop
I <<	I <<
>>I	>>I
Setup	Options
Source	AV
Info	Info
Return/Exit	Exit
CH+	Ch +
CH-	Ch -
Up	Up

Original	Sustituto
Down	Down
Right	Right
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Slow	Back

Original		Sustituto	
GOTO	Goto	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
TITLE/TTX	Title/TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
REPEAT	Red/Repeat	A	Red
A-B	Green/A-B	B	Green
MENU	Yellow/Menu	C	Yellow
ANGLE	Blue/Angle	D	Blue
EPG	EPG	-/-- GUIDE	Guide
FAVORITE	Favorite	FAV PRE-CH	Pre Ch
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject

Original	Sustituto