Original		Sustituto	
STANDBY	Standby		Power
OPEN/CLOSE	Open / Close	ZOOM	Eject
ANGLE	Angle	PICTURE FORMAT	Format
DISPLAY/INFO	Display / Inf	DISPLAY INFO	Info
Q-PLAY/TV/RADI	Q-Play / TV/Radi	SEARCH TV/R	TV/R
Q-PLAY/TV/RADI	Q-Play / TV/Radi	SHIFT + PLAY MODE	Shift + Play
P/N/EPG	P/N / EPG	-/-- GUIDE	Guide
SEARCH/TTX	Search / TTX	REPEAT TEXT	Text
SEARCH/TTX	Search / TTX	SHIFT + SEARCH TV/R	Shift + TV/R
PBC/LIST	PBC / List	DISC NAV LIST	List
SUBTITLE	Subtitle	AD SUBT	Subt
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

Original		Sustituto	
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
RANDOM	Random	HOME SMART	Smart
AUDIO	Audio	SOUND DUAL	Dual
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL -	Vol -
STOP	Stop	■	Stop
PLAY	Play	PLAY MODE ▶	Play
PAUSE	Pause	❚❚	Pause
PREV	Red / Prev	A	Red
PREV	Red / Prev	⏮	I<<
NEXT	Green / Next	B	Green
NEXT	Green / Next	⏭	>>I
REW	Yellow / REW	C	Yellow
REW	Yellow / REW	≪	<<

Original		Sustituto	
FF	Blue / FF	D	Blue
FF	Blue / FF	>>	>>
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
CH+	Up / CH+		Up
CH+	Up / CH+	+ CH	Ch +
	Down / CH-		Down
	Down / CH-	CH −	Ch -
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TITLE/Pg Up	Title / Pg Up	SHIFT + + CH	Shift + Ch +
TITLE/Pg Up	Title / Pg Up	APP MEDIA	Media
MENU/Pg Dn	Menu / Pg Dn	TOP MENU MENU	Menu
MENU/Pg Dn	Menu / Pg Dn	SHIFT + CH −	Shift + Ch -
ZOOM/PVR	Zoom / PVR	SHIFT + ZOOM	Shift + Eject
REPEAT	Rec / Repeat	REC MODE	Rec

Original		Sustituto	
REPEAT	Rec / Repeat	SHIFT + REPEAT TEXT	Shift + Text
A-B/FAV	A-B / FAV	FAV PRE-CH	Pre Ch
SLOW/EXIT	Exit / Slow	CLEAR EXIT	Exit
VIDEO	Video	SHIFT + TIMER AV	Shift + AV
SLOW/EXIT	Exit / Slow	SHIFT + >>	Shift + >>
STEP	Step	SHIFT + II	Shift + Pause
DVD/DVB	DVD / DVB	TIMER AV	AV
MUTE	Mute	MUTE	Mute