Original		Sustituto	
	Power		Power
	Input TV		AV / Input / RDS
	Input Av		Shift + AV / Input / RDS
	Aspect		Picture / Format
	Viera Link		Smart / List
	Option		Setup / OPT /
	Direct TV Rec		Rec / Rec Mode
	Guide		Guide / EPG / -/--
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down
	Return		Back / Return
	Red		Red / Netflix / Search

Original		Sustituto	
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	STTL		Subtitle / EQ
	Index		TV/Radio /
	Hold		Shift + Stop /
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
i	i		Info / Angle

Original		Sustituto	
0 VCR	0 / VCR	HDMI - SAT 0	0
0 VCR	0 / VCR	SHIFT + VIDEO 4	Shift + 4
	Mute	DIMMER MUTE	Mute / Dimmer
	CH+	+ CH PAGE	CH+ / Page+
	Vol +	+ VOL	Vol +
	CH-	CH PAGE −	CH- / Page-
	Vol -	VOL −	Vol -
	DVD Power	SHIFT +	Shift + Power
REC	DVD Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
PROGR	DVD	SHIFT + CH PAGE −	Shift + CH- /
RAMME	DVD	SHIFT + + CH PAGE	Shift + CH+ /
	DVD << / I <<	PRESET-	I << / Preset-
	DVD << / I <<	TUNE-	<< / Tune-
	DVD >> / >>I	TUNE+	>> / Tune+
	DVD >> / >>I	PRESET+	>>I / Preset+
	DVD Stop	HOLD	Stop / Hold
	DVD Pause / Step	STEP - FREEZE	Pause / Step / Freeze

Original		Sustituto	
	DVD Play	SLOW	Play / Slow

Original	Sustituto	Original	Sustituto
Power DVD	Power		
Rec DVD	Rec / Rec Mode		
Programme Down	CH- / Page-		
Programme Up	CH+ / Page+		
I << DVD	I << / Preset-		
<< DVD	<< / Tune-		
>>I DVD	>>I / Preset+		
>> DVD	>> / Tune+		
Stop DVD	Stop / Hold		
Pause/Step DVD	Pause / Step / Freeze		
Play DVD	Play / Slow		

Original	Sustituto	Original	Sustituto
VCR Power	Power		
VCR Rec	Rec / Rec Mode		
VCR	CH- / Page-		
VCR	CH+ / Page+		
VCR << / I <<	<< / Tune-		
VCR << / I <<	I << / Preset-		
VCR >> / >>I	>>I / Preset+		
VCR >> / >>I	>> / Tune+		
VCR Stop	Stop / Hold		
VCR Pause / Step	Pause / Step / Freeze		
VCR Play	Play / Slow		