Original		Sustituto	
	Power MD		Power
	TV		TV/R
	CD		Yellow
	DVD		Blue
	Tuner/Band		Green
	Tape		Red
	VCR		Smart
	MD		Media
	Vol +		Vol +
	Vol -		Vol -
	Muting		Mute
	Stop MD		Stop
	Play MD		Play
	<</I<< MD		<<
	>>/>>I MD		>>
	Up		Up
	Down		Down

Original		Sustituto	
	Right		Right
	Left		Left
	Enter		Ok
	Menu		D. Menu
	Display		Info
	Top Menu/Disc/Deck		Menu
	1 MD		1
	2 MD		2
	3 MD		3
	4 MD		4
	5 MD		5
	6 MD		6
	7 MD		7
	8 MD		8
	9 MD		9
	0 MD		0
	>10/-/-- MD		Guide

Original		Sustituto	
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
	Power TV	SHIFT +	Shift + Power
VOL ^	Tv Vol Up	SHIFT + VOL +	Shift + Vol +
TV VOL	Tv Vol Down	SHIFT + VOL -	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5

Original		Sustituto	
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original		Sustituto	
	Power DVD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	Tuner/Band	B	Green
	Tape	A	Red
	MD	APP MEDIA	Media
	CD	C	Yellow
	DVD	D	Blue
	Play DVD	PLAY MODE	Play
	I<</<< DVD	<<	<<
	Stop DVD		Stop
	>>/>>I DVD	>>	>>
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Display	DISPLAY INFO	Info
	Menu	E-MANUAL D.MENU	D. Menu
	Up		Up
	Down		Down

Original		Sustituto	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
1	1 DVD	1	1
2	2 DVD	2	2
3	3 DVD	3	3
4	4 DVD	4	4
5	5 DVD	5	5
6	6 DVD	6	6

Original		Sustituto	
7	7 DVD	7	7
8	8 DVD	8	8
9	9 DVD	9	9
0	0 DVD	0	0
≥10/-/--	>10/-/-- DVD	-/-- GUIDE	Guide
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute

Original	Sustituto

Original		Sustituto	
	Power CD		Power
	TV		TV/R
	VCR		Smart
	CD		Yellow
	DVD		Blue
	Tape		Red
	MD		Media
	Tuner/Band		Green
	Stop CD		Stop
	I<</<< CD		<<
	>>/>>I CD		>>
	Play CD		Play
	Menu		D. Menu
	Display		Info
	Top Menu/Disc/Deck		Menu
	Up		Up
	Down		Down

Original		Sustituto	
	Right		Right
	Left		Left
	Enter		Ok
	Stereo		Dual
	Surround		Options
	SFC		Subt
	Test		Back
	Delay		Format
	Level		3D
	+		Ch +
	-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Muting		Mute
	Power Tape		Shift + Power
	Stop Tape		Shift + Stop
	Play Tape		Shift + Play

Original		Sustituto	
I <</ << Tape		SHIFT + <<	Shift + <<
>>/ >>I Tape		SHIFT + >>	Shift + >>
Top Menu/ Disc/ Deck		SHIFT + TOP MENU / MENU	Shift + Menu
1 CD- Tape		1	1
2 CD- Tape		2	2
3 CD- Tape		3	3
4 CD- Tape		4	4
5 CD- Tape		5	5
6 CD- Tape		6	6
7 CD- Tape		7	7
8 CD- Tape		8	8
9 CD- Tape		9	9
0 CD- Tape		0	0
>10/ - / - - CD- Tape		-/-- GUIDE	Guide
Direct Tuning/ Disc Ente		REPEAT TEXT	Text

Original	Sustituto

Original		Sustituto	
	Power VCR		Power
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
MD	MD	APP MEDIA	Media
	Stop		Stop
	I<</<<		<<
	>>/>>I		>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5

Original		Sustituto	
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING/ DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info

Original		Sustituto	
MENU	Menu	E-MANUAL D.MENU	D. Menu
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
Power	Power Tuner/Band	SHIFT + Power	Shift + Power
1	1 Tuner/Band	SHIFT + 1	Shift + 1
2	2 Tuner/Band	SHIFT + 2	Shift + 2
3	3 Tuner/Band	SHIFT + 3	Shift + 3
4	4 Tuner/Band	SHIFT + 4	Shift + 4
5	5 Tuner/Band	SHIFT + 5	Shift + 5
6	6 Tuner/Band	SHIFT + 6	Shift + 6
7	7 Tuner/Band	SHIFT + 7	Shift + 7

Original		Sustituto	
8	8 Tuner/Band	SHIFT + 8	Shift + 8
9	9 Tuner/Band	SHIFT + 9	Shift + 9
0	0 Tuner/Band	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/--	SHIFT + -/-- GUIDE	Shift + Guide